

DRYVAC DV 650, DV 800

Dry Compressing Vacuum Pumps


Operating instructions 301042728_002_C2

Part Numbers

112065V05-1 /07-1 /09-1 /
11-1 /12-1 /14-1 /14-2 /
14-3 /15-1 /16-1 /17-1 /
18-1 /19-1 /19-2 /20-1 /
30-1 /32-1 /35-1 /36-1 /
37-1 /75-1

112065FP08-1 /18-1 /
28-1 /29-1

112080V05-1 /07-1 /12-1 /
14-1 /15-1 /17-1 /75-1



Copyright notice

©Leybold GmbH. All rights reserved.

Published: 2/6/2023

Associated publications

Publication title	Publication number
Bus Interfaces	301076031
EMC Filter	301140450

Trademark credit

Leybold and the Leybold logo are trademarks of Leybold GmbH, Bonner Strasse 498, D-50968 Cologne.

Disclaimer

The content of this manual may change from time to time without notice. We accept no liability for any errors that may appear in this manual nor do we make any expressed or implied warranties regarding the content. As far as practical we have ensured that the products have been designed and constructed to be safe and without risks when properly installed and used in accordance with their operating instructions.

We accept no liability for loss of profit, loss of market or any other indirect or consequential loss whatsoever.

Product warranty and limit of liability are dealt with in our standard terms and conditions of sale or negotiated contract under which this document is supplied.

You must use this product as described in this manual. Read the manual before you install, operate, or maintain the product.

Contents

1 Safety and compliance.	8
1.1 Definition of Warnings and Cautions.	8
1.2 Trained personnel	8
1.3 Safety symbols.	9
2 Important safety information.	10
2.1 Mechanical hazards.	11
2.2 Electrical hazards.	12
2.3 Thermal hazards.	13
2.4 Hazards caused by materials and substances.	14
2.5 Ignition risk.	15
2.6 Noise hazard.	15
2.7 Dangers in connection with safety-related measures and precautions.	16
2.8 Danger of pump damage.	16
3 Description.	18
3.1 Design.	18
3.2 Supplied equipment.	18
3.3 Conforming use.	19
3.3.1 Non-conforming use.	19
4. Technical data.	21
5 Transport.	26
6 Installation.	27
6.1 Dimension drawings.	27
6.2 Placement.	29
6.3 Connect the intake and exhaust lines.	30
6.3.1 Intake lines.	30
6.3.2 Exhaust lines.	31
6.4 Cooling water connection.	32
6.4.1 Water quality.	34
6.5 Connect the purge gas.	35
6.5.1 Gas ballast valve.	39

Contents

6.5.2 Guidelines for purge gas operation, settings and monitoring	40
6.6 Electrical connection.	44
6.6.1 Electrical schematic.	46
6.6.2 Electrical connection DRYVAC DV 650 and DV 800.	51
6.6.3 Electrical connections DRYVAC DV 650-r and DV 800-r	53
6.7 Leak search after installation.	55
6.8 Mounting accessories.	56
6.8.1 Roots pump adapter.	56
6.8.2 Non-return valve.	56
7 Operation.	59
7.1 Media compatibility.	59
7.2 Field-bus interface.	59
7.3 Start-up.	59
7.4 Pump control connections.	60
7.4.1 LED operator and keys.	60
7.4.2 Power on.	62
7.4.3 Frequency converter outputs.	62
7.4.4 Relay option board.	65
7.4.5 Option: Change the speed of the pump.	66
7.4.6 Gas ballast operation.	68
7.4.7 Pumping of 100% Argon.	68
7.5 Shut-off and vent.	68
7.5.1 Process pump recovery after pump failure.	69
7.5.2 Remove from service.	69
8 Maintenance.	70
8.1 Maintenance intervals.	70
8.2 Change the oil.	70
8.3 Cleaning the filter insert in the cooling water pressure reducer	73
8.4 Check and clean the gas ballast filter.	73
8.5 Replace the filter cartridge in the purge gas pressure reducer	73
9 Fault finding.	74
9.1 Fault and alarms displayed at the frequency converter.	78

Contents

9.2 Operator programming errors.	82
10 Storage.	84
11 Disposal.	85
11.1 Disposal of waste oil.	85
12 Service.	86
12.1 Return the equipment or components for service	86
13 Accessories.	87
13.1 Ordering information.	88
13.2 Wearing parts.	91
14 Legal declarations.	92

List of Figures

Figure 1. Pump models.	18
Figure 2. Permissible gas inlet temperature as function of the inlet pressure.	25
Figure 3. Lifting the DRYVAC.	26
Figure 4. DRYVAC DV 650, DV 800.	27
Figure 5. DRYVAC DV 650-r, DV 800-r.	28
Figure 6. Connections for the DRYVAC.	29
Figure 7. Oil level in the DRYVAC oil glasses.	30
Figure 8. Intake flange connections.	31
Figure 9. Cooling water connection.	34
Figure 10. Triple purge gas module.	36
Figure 11. Double purge gas module and 24 V gas ballast - version 1.	36
Figure 12. Double purge gas module and 24 V gas ballast - version 2.	37
Figure 13. Double purge gas module.	37
Figure 14. Single purge gas module.	38
Figure 15. Electropneumatic gas ballast valve (option).	40
Figure 16. Double purge gas module with gas ballast valve (top view).	40
Figure 17. Purge gas and switches schematic.	43
Figure 18. Symmetric grounding.	45
Figure 19. Mains and control circuit wiring DRYVAC.	48
Figure 20. Control I/Os.	49
Figure 21. Circuit diagram for the purge gas pressure switch. .	50
Figure 22. Option: Wiring with external power supply.	51
Figure 23. Frequency converter without covers.	52
Figure 24. Establishing the potential equalisation at the pump casing.	53
Figure 25. Main and control circuit wiring.	54
Figure 26. Junction box of DRYVAC.	55

List of Figures

Figure 27. Roots pump adapters.....	56
Figure 28. Non-return valve 112005A15 with swivel joint.....	57
Figure 29. Side view/sectional view of the non-return valve with swivel joint.....	58
Figure 30. Non-return valve 112005A14 for DRYVAC DV 650/800.....	58
Figure 31. LED operator.....	60
Figure 32. Relay option board - Connections.....	65
Figure 33. Set the second set point frequency.....	66
Figure 34. Control the pump speed.....	67
Figure 35. Oil change.....	72
Figure 36. Maintenance on the air filter at the gas ballast valve.	72
Figure 37. Capacitor forming.....	84

Safety and compliance

1 Safety and compliance

For safe operation from the start, read these instructions carefully before you install or commission the equipment and keep them safe for future use. Read all the safety instructions in this section and the rest of this manual carefully and make sure that you obey these instructions.

The instruction manual is an important safety document that we often deliver digitally. It is your responsibility to keep the instruction manual available and visible while working with the equipment. Please download the digital version of the instruction manual for use on your device or print it if a device will not be available.

1.1 Definition of Warnings and Cautions

Important safety information is highlighted as warning and caution instructions which are defined as follows. Different symbols are used according to the type of hazard.

WARNING:

If you do not obey a warning, there is a risk of injury or death.

CAUTION:

If you do not obey a caution, there is a risk of minor injury, damage to equipment, related equipment or process.

NOTICE:

Information about properties or instructions for an action which, if ignored, will cause damage to the equipment.

We reserve the right to change the design and the stated data. The illustrations are not binding.

1.2 Trained personnel

For the operation of this equipment “trained personnel” are:





- skilled workers with knowledge in the fields of mechanics, electrical engineering, pollution abatement and vacuum technology and
- personnel specially trained for the operation of vacuum pumps

Safety and compliance

1.3 Safety symbols

The safety symbols on the products show the areas where care and attention is necessary.

The safety symbols that we use on the product or in the product documentation have the following meanings:

	Warning/Caution An appropriate safety instruction must be followed or caution to a potential hazard exists.
	Warning - Automatic start up The equipment can be remotely started.
	Warning - Corrosive substances The substance is corrosive.
	Warning - Dangerous voltage Identifies possible hazards from hazardous voltages.
	Warning - Flammable material The material is flammable. If exposed to sources of ignition it can cause a fire.
	Warning - Hot surfaces Identifies a potential hazard from a hot surface.
	Warning - Noise hazard Risk of high noise levels in this area. Hearing protection must be worn when this equipment is in operation.
	Warning - Risk of explosion There is a risk of explosion when you do the task.
	Warning - Toxic material The material is toxic.
	Warning - Overhead or Suspended load Do not stand below the suspended load.
	Warning - Wear eye protection Risk of Injury. Wear protective goggles when checking the direction of rotation.
	Warning - Wear hearing protection
	Warning - Protective earth (ground) Earth point for electrical equipment.

Important safety information

2 Important safety information



WARNING: HAZARDOUS WORKING CONDITIONS

Risk of injury. The pump must be leak tight. When the pump has been used to pump hazardous gases before, introduce appropriate safety precautions before opening it. Before opening the pump, purge it for a longer period of time with an inert gas. If necessary, wear suitable personal protection equipment like gloves, breathing protection and protective clothing, for example.



WARNING: DANGEROUS VOLTAGE

Risk of electric shock. Disconnect power before opening. Contact causes electrical shock. There can be a high leakage current. Earth connection is necessary before connecting supply. Danger of residual voltage for up to 5 minutes after disconnecting power supply. Connect and disconnect the mains plug only in de-energised condition.



WARNING: HOT SURFACES

Risk of burns. Do not touch. Allow this area to cool before servicing. Hot surface inside. Do not touch, wear protective equipment.



WARNING: EXPLOSION HAZARD

Risk of injury or damage to the equipment. Check compatibility with applications of the purge gas. Overpressure in the discharge line. Components can be thrown in all directions. The pressure in the discharge line must not exceed 1200 mbar. The discharge line must not be blocked or restricted.



CAUTION: PUMP WITH WHEELS

Must only be placed and moved on levelled horizontal surfaces.



CAUTION: VACUUM

Avoid exposing any part of the human body to the vacuum.



CAUTION: AUTOMATIC START UP

Connect the pump so that it will not restart automatically after a mains power failure, once the power returns.

Important safety information



CAUTION: SUSPENDED LOAD

Transport the pump only at the four crane eyes or secured with a forklift.

2.1 Mechanical hazards

1. To avoid the destruction of systems and injury to operating personnel we urgently recommend to observe the information and installation information provided in these operating instructions.
2. Avoid exposing any part of the human body to the vacuum.
3. Do not operate the pump with an opened intake port. There exists the risk of suffering injury.
4. The pump is intended for generating a vacuum only. If an overpressure occurs in the pump and the system then they must be protected against such an overpressure by an overpressure safety valve, for example.
5. The maximum permissible discharge pressure for the DRYVAC is 1200 mbar.

Always operate the pump with a connected exhaust line. The exhaust line must be designed for the specific kind of application and shall be connected to a central exhaust gas system.

Make sure that the gas flow at the discharge is not blocked or restricted in any way, even when the pumped out gases need to be collected or contained.

No shutoff devices are required in the discharge line for pump operation. If shutoff devices are installed, open them before starting the pump.

In the case of processes involving much condensate, we recommend the installation of a condensate separator in the discharge line.

6. When using purge gas, protect the purge gas supply so that in the event of a malfunction or power interruption no overpressure can occur within the pump system.
7. We recommend to design the discharge line in consideration of a possible overpressure of 10 bar. In the event of a malfunction, an overpressure can occur briefly, for example, when the exhaust is shut suddenly.
8. For transporting the pump use only suitable transportation equipment.
When selecting the lifting and transport equipment take note of the total weight before transporting the pump.
As standard, the pump has been equipped with four crane eyes.
When transporting the pump with a forklift or similar, make sure that the pump has been secured on the forks or on a suitable pallet and all the cables at the bottom of the pump are carefully secured.
The lifting eye of the screw pump must never be used to lift any pump combinations (roots pump + backing pump).
9. Select the location where the pump is installed so that all controls can be easily accessed. Place the pump only on a floor which is level. It can topple when it is tilted by more than 10 degree with respect to the vertical axis.

Important safety information

10. For pumps on castors only:
Because of the installed castors, the pump must only be placed on a levelled floor capable of supporting the pump's weight, as there exists the risk of the pump rolling away. Moreover, the pump may only be moved on a levelled floor. Moving the pump along sloping paths or ramps is prohibited. The pump must only be transported with a forklift or a crane. At the installation location, screw down the adjustable feet.
11. Before beginning with any maintenance and servicing work always make sure that no gas can flow backwards through the pump as the rotors might turn against the normal direction of rotation. For this reason vent the vacuum chamber to the discharge pressure level or make sure that the vacuum chamber and the lines are reliably separated from the pump through suitable valves. When connecting several pump systems, pressure differences between inlet and discharge can give rise to uncontrolled turning of the pump's shafts.
12. During operation, the cooling water circuit must not be shut off. A cooling water discharge which has been blocked can cause the formation of gas bubbles and result in excessively high pressures.
13. Lay electric feed and cooling water lines so that there is no risk of tripping over these.
14. When you change the oil remove any escaped oil as there is the risk of slipping.
15. Before doing installation work on the pump system make sure that no vacuum is present in the pump and that all media connections have been depressurised.
16. Before you disassemble any cooling water lines, leave the pump to cool down, shut off the feed line.

2.2 Electrical hazards

WARNING: DANGEROUS VOLTAGES



Risk of electric shock. Potentially lethal voltages are present at the mains connections. Before you begin any maintenance or service work on the pump, disconnect the pump from all power supplies (lockout/tagout). In addition, there is the danger of residual voltage for up to 5 minutes after disconnection. When touching parts at high electric voltages, there is the risk of suffering severe injuries by an electric shock. Covers marked with this symbol must only be opened by trained electricians after having reliably de-energised (lockout/tagout) the equipment.

1. The electrical connection must only be provided by a trained person. Observe the national regulations in the country of use like EN 50110-1 for Europe, for example.
2. Install a device for a safe disconnection from the power supply.
3. Note the information on the IP type of protection.
4. Always operate the pump with a properly connected protective earth conductor and make sure that the motor casing is closed.
5. Observe the manufacturer's information and operating instructions for the respective frequency converter.
6. The pump must only be operated at the frequency specified for the motor. Use only our frequency converter.

Important safety information

7. For pumps with external frequency converter: After connecting the motor and each time after changes are made to the wiring, check the motor's direction of rotation.
A wrong direction of rotation can cause a pressure build-up on the intake side. Moreover, the pump may suffer severe damage.
8. Install a suitable motor protection for the electric motor before starting up for the first time. Note the information in these operating instructions and on the nameplate.
9. Before you start, make sure that the junction box is undamaged, do a visual inspection of the seals.
10. Install add-on parts (pressure switches, for example) without any mechanical tensions and protect these against being damaged by impacts, for example.
11. Lay the connecting lines so that these cannot be damaged. Protect the lines against humidity and contact with water. Avoid thermally stressing the lines by unfavourable laying. Comply with the required standards when designing and laying the electrical connections.
12. Provide strain relief for the connecting lines so that the plugs and the line connectors are not subjected to excessively high mechanical stresses.
13. Lay electric feed lines so that there is no risk of tripping.
14. For models with external frequency converter only:
Consider the following precautions for the output circuit wiring.
Do not connect any other load than a three phase motor to the frequency converters output.
Never connect a power source to the frequency converters output.
Never short or ground the output terminals.
Do not use phase correction capacitors.
15. The pump must be integrated in the system control arrangement so that it can not run-up automatically after it has been shut down due to over-temperature. This applies equally to emergency shut-down arrangements. After having determined the fault cause, the pump should be switched on manually again.
16. We recommend the use of the external display (accessory) to operate the frequency converter. Attach the external display appropriately if it is to be used permanently.
17. Work on the frequency converter within the motor casing must be done by trained personnel only.

2.3 Thermal hazards



WARNING: HOT SURFACE

Risk of burns. During operation the pump is hot and some surfaces can reach a temperature higher than 80 °C. Note the danger symbols on the pump and in the case of a hot pump wear the required protection equipment. If there is the risk of touching hot surfaces inadvertently, install corresponding protection. When working on a pump which is still warm from operation, always wear protective gloves.

1. Handle the pump only while vented and after having let it cool down.
2. Before you disassemble any cooling water lines, leave the pump to cool down, shut off the feed line.
3. When you uninstall the cooling water lines, take note of splashing water. Heated water can cause burns.

Important safety information

4. Never remove the oil-fill or oil-drain plugs while the pump is running. There exists the risk of suffering burns. Always wear protective gloves and protective goggles also for protection against the oil.
5. Operating the pump with less than the specified amount of cooling water will result in excessively high surface temperatures. Moreover, there exists the risk of suffering burns.
6. DRYVACs without cooling water unit:
(Industrial versions) For these DRYVAC pumps do not connect the cooling water using self-sealing quick locks or shut off the feed and discharge lines with valves.
After switching off, the pump will continue to produce heat. If upon switching off the pump someone would then interrupt the cooling water flow (through quick locks or valves on both sides (feed and discharge)) then the water will continue to heat up further but will not be able to expand. The high pressure thus produced may cause damage to the cooling water channels and seals. Moreover, hot water or steam may escape.

2.4 Hazards caused by materials and substances



WARNING: HAZARDOUS GASES

Risk of injury or damage to the equipment. The vacuum line and the exhaust line must be leak tight. Hazardous process gases may escape or the pumped gases can react with air or atmospheric humidity. After installation of the pump and after servicing work on the vacuum system, a leak search will always be necessary. When pumping hazardous gases we recommend a leak search on a regular basis. Leaks in the pump cannot be ruled out under all circumstances. When pumping hazardous gases, the operator must make sure that leaks at the pump will not be a hazard.



WARNING: CONTAMINATION HAZARD

Risk of exposure. Contaminated parts can be detrimental to health and the environment. Before beginning with any repair and maintenance work inform yourself about any possible contamination. When handling contaminated parts observe the pertinent regulations and comply with the necessary protection measures. If the pump has been contaminated by the process or through environmental influences, it must be decontaminated professionally. When shipping contaminated pumps which require approval by the authorities, note the applicable regulations regarding packaging and shipping.

The cooling water from the return is not of drinking water quality and should not be used for this purpose. After having operated the pump, the cooling water lines may suffer from microbiological contamination. Take appropriate safety precautions.

-
1. Since not all application related hazards for vacuum systems can be described in detail in these operating instructions, we have made available a separate document (safety booklet) in which the hazards and general safety concepts for design, operation and maintenance of vacuum systems are explained.
When planning to pump hazardous substances with this pump, read the related chapters in the safety booklet and in these operating instructions first. You can download the safety booklet from our homepage.
 2. Before commissioning the pump, make sure that the media which are to be pumped are compatible with each other so as to avoid hazardous situations.

Important safety information

3. If required additional monitoring of the purge gas quantities is necessary from the side of the operator when a well-defined and ensured dilution is necessary from the side of the process.
The type of protection depends on the specific process and needs to be assessed by of the customer.
4. Before operating the pump with a gas ballast or a purge gas check the compatibility of the gas with the pumped media so as to avoid dangerous conditions during operation.
5. When the pump has been used to pump hazardous gases before, introduce appropriate safety precautions before opening the intake or the discharge connections. Before opening the pump, purge it for a longer period of time with an inert gas. If necessary, wear suitable personal protection equipment like gloves, breathing protection and protection clothing, for example (see material safety data sheets for the substances in use, the chemical reactions and the by-products). Firmly seal off the pump. When shipping the decontaminated pump for servicing also indicate the type of hazard. For this see [Service](#) on page 86.
6. We are not in a position to perform servicing (repairs) and waste disposal of radioactively contaminated pumps. Both needs to be ensured from the side of the user.
7. When disposing of the pump, used lubricants and used oil filters observe the applicable environment regulations.
8. When pumping hazardous gases you must assume the presence of hazardous residues in the pump.
9. Some pumps use Perfluoropolyether (PFPE) as lubricant. When handling PFPE you should observe the following: During thermal decomposition at temperatures over 290 °C toxic and corrosive gases are released. When handling PFPE keep it away from open fires. Do not smoke with PFPE on your fingers. Touch the inner sections of the pumps only while wearing clean gloves, and use clean tools; do the necessary work in clean and dry rooms. After the pump is removed from its packaging, start it up as quickly as possible. Solvents based on hydrofluorether compounds may be used as cleaning agents.
10. Fluoropolymers are used as sealants (FKM) and as lubricants (PFPE) in the pumps. In case the pump suffers a severe mechanical failure, the possibility of hazardous substances being released owing to their thermal decomposition cannot be excluded. The hazards caused by such decomposition are described in the material safety data sheets for the materials, for example.

2.5 Ignition risk

The standard version of the pump is not suited for operation in explosion hazard areas. Contact us before planning to use the pump under such circumstances.

2.6 Noise hazard

The noise level of the pump during ultimate pressure operation with silencer or connected discharge line corresponds to the values stated in the [Technical data](#) on page 21. In other operating modes and with other equipment, higher values must be expected. Make sure that suitable protection measures are taken to protect your hearing.

We recommend to wear hearing protectors (earmuffs), if local noise levels exceed mandatory limits.

Important safety information

2.7 Dangers in connection with safety-related measures and precautions



WARNING: AUTOMATIC RESTART

Risk of injury and damage to the equipment. For the pumps being operated with a frequency converter, after a mains power failure the pump will automatically start up again once the power returns.

1. The pump is not equipped with an emergency shutdown facility.
2. If there is power supply failure for less than 2 seconds, the frequency converter will start again, if more than that the frequency converter will not start again.
3. Take note of the warning information on the casing surface. If this warning information was removed, covered or obstructed, then provide corresponding additional warning information.

2.8 Danger of pump damage

1. Select an installation site for the pump so that all controls are easily accessible.
2. The pumps are supplied filled with lubricant (synthetic oil or PFPE). For this reason they should, while being transported or shipped, not be subjected to much tilting. Store the pumps only horizontally standing on their feet.
3. Do not allow the ingestion of any objects (screws, welding beads, nuts, washers, pieces of wire, etc.) through the intake port of the pump.

If possible, use the intake screen which has been fitted as standard and clean it regularly.

In case the pump is operated without intake screen the operator has to make sure that no objects can enter the pump through the intake port. Objects falling into the pump can cause severe damage at the pump including leaks to atmosphere. The intake screen does not replace a filter. Prevent the intake of particles from the side of the process by fitting suitable filters. Upstream filters protect the pump against damage to the pump chamber.

4. In a pumping section (combination of several pumps connected in series) only a single intake screen is required. This screen needs to be fitted to the inlet for the pump closest to the process chamber. When pumping dust containing media, install a dust filter in the process gas flow upstream with respect to the pump.
5. If low concentration corrosive or reactive gases are being pumped, then operate the pump with purge gas.
Consult us to determine which pump types are required for specific processes and applications.
6. When connecting the pump, provide a suitable valve on the intake side for the purpose of shutting off the intake line so as to prevent the pump from turning backwards in the event of a power failure. Otherwise the pump may suffer damage or oil may contaminate the pump chamber.
7. Lines and other vacuum connections should be clean and free of oil. Special attention must be paid here when oil-sealed pumps have been used on the vacuum side. Check the conditions before initial commissioning. In the case of deviations, the pump can suffer contamination with oil residues.

Important safety information

8. The pressure within a pump which has been switched off will increase to ambient pressure within a few seconds. In such a case the pump is vented through the discharge. We recommend to fit a non return discharge valve.
9. The discharge line should be laid so that it slopes down and away from the pump so as to prevent condensed vapours from backstreaming into the pump.
10. In the case of wet processes we recommend the installation of liquid separators, upstream and downstream of the pump so as to avoid the influx of liquid into the pump.
11. During installation work on the intake and discharge lines do not subject flanges to any stresses. Check the rubber elements of the pump's feet as to any deformation.
12. Before pumping condensable vapours the pump should be at operating temperature. If a gas ballast is present, then it should be opened. The pump will attain its operating temperature approximately 30 minutes after having started the pump. During this warm-up phase, the pump should be left separated from the process by a valve in the intake line, for example.
13. With the pump warm from operation do not clean it from the outside with water or suddenly supply very cold cooling water. There is the risk of a rotor crash due to shock cooling.
14. If condensable vapours have been pumped, the pump should before switching off be purged for approximately 15 minutes with an inert gas or air (depending on the specific application). This process should also be run before cleaning the pump chamber.
15. Improper decommissioning of the pump may damage it. For this reason, follow the instructions given in [Shut-off and vent](#) on page 68 and [Remove from service](#) on page 69 of these operating instructions.
16. Improper maintenance or repair work can have an influence on the service life and the performance of the pump and will void any warranty claims.
17. Maximum cooling water pressure: 7 bar. When exceeded, there is the risk of leaks.

 **Note:**

Pressures given in bar or mbar are absolute values. If exceptionally a gauge pressure is meant, a "g" is added (bar(g)).

Description

3 Description

3.1 Design

The DRYVAC is a dry compressing screw vacuum pump. The DRYVAC DV 650 and 800 pumps are equipped with one screw pumping stage.

We offer different pump models for different applications. DRYVAC Industrial versions pumps cover all features needed for process industry applications. For example, they are equipped with a gas ballast facility.

DRYVAC Industrial versions and the DRYVAC S have optimised pumping speeds at pressures more than 100 mbar. These models are specially suited for short cycle operation, for example, load lock applications.


Models from the DRYVAC C range have been designed to provide reliability in harsh process duties. They are optimised for handling typical gases from the production in the PV and FPD industry. They excel through their robust design and meet industrial safety requirements. They are equipped with a purge gas system that facilitates rotor purge and shaft seals purge.

All DRYVAC pumps are basically equipped with the same motor. The required frequency converter has either been installed at the pump or is installed separately in a rack (-r models).

All DRYVAC pumps have been prepared for direct fitting of a RUVAC roots pump.

The pumps are water cooled. They are lubricated either with synthetic oil or PFPE.

Figure 1. Pump models



A. DRYVAC DV 650, DV 800

B. DRYVAC DV 650-r, DV 800-r

3.2 Supplied equipment

- Pump as described in [Design](#) on page 18 and [Ordering information](#) on page 88 have the external frequency converter included in the delivery.
- The pumps are filled with lubricant:
Synthetic oil LEYBONOL LVO 210 or PFPE LEYBONOL LVO 410.
- The pumps are purged with nitrogen for protection against corrosion. The pump flanges have been blanked off with a sealing cap.
- 4x crane eyes M16
- Intake screen with O-ring
- 3x plugs for purge gas valve (only with installed purge gas module)
- Plug for purge gas pressure switch (only with installed purge gas module).

3.3 Conforming use

DRYVAC pumps with synthetic oil

DRYVAC pumps with synthetic oil are load lock, transfer and process pumps for medium rough processes. Their deployment in combination with much oxidising media is not recommended.

When assessing media compatibility here, in particular the hazards resulting from the reaction of the process gases with the hydrocarbons must be assessed. For this read the information given in the safety booklet or consult us for details.

DRYVAC pumps are screw vacuum pumps developed for deployment in connection with medium to rough applications. The pumps have been designed for applications in the process industry and for thin film coating (solar, glass coatings, display coatings, for example).

Basically, all DRYVAC pumps are leaktight and may for this reason be utilised for pumping toxic and potentially flammable gases outside their ignition range. For such applications, note the safety information given in [Hazards caused by materials and substances](#) on page 14. When using the pumps in connection with oxidising or corrosive gases, check media compatibility first. Media compatibility and the resulting hazards of each substance used and also of each substance mixture need to be reassessed on a case-by-case basis.

There are different product variants (see [Ordering information](#) on page 88) for different application focuses.

DRYVAC pumps with PFPE

DRYVAC pumps with PFPE offer a higher level of media compatibility.

DRYVAC C

DRYVAC C pumps are process pumps also suited for operation with much oxidising and corrosive media. With these pumps, you may pump both toxic and potentially flammable gases outside their ignition range and a large number of corrosive and much oxidising substances and substance mixtures.

When planning to pump hazardous substances always consult us first.

3.3.1 Non-conforming use



WARNING: NON-CONFORMING USE

Risk of injury or damage to equipment. The non-conforming use of pump and accessories may result in severe injury or damage to the components.

Non-conforming use for the pump are as follows:

- Operation with limit parameters which are not programmed by us, particularly the maximum speed.
- Pumping of gases and vapours for which the materials of the pump are not suited, consult us. For a list of materials in contact with the process gases, see [Technical data](#) on page 21.
- Pumping of substances and mixtures (gases, liquids and solids) which are rated as being explosive.

Description

- Pumping of condensable vapours without adequately controlling the temperature of the pump. Upon compression in the pump, these vapours may condense or form deposits, consult us.
- Pumping of dusts and solids without suitable screens and filters, consult us.
- Pumping of liquids
- Pumping of ignitable gas mixtures
- Pumping of process gases which form hard or sticky deposits which may cause the pump to seize.
- The use of pump and frequency converter in the explosion hazard areas
- Non-compliance with the described maintenance and service intervals.
- Use in systems and pump systems in which the exhaust pressure may increase over 1.2 bar absolute.
- Operation with an inadequately affixed pump.
- Operation at impermissibly high gas temperatures
- Use in systems where pump, frequency converter and cables are subjected to impact stresses.
- Operation on movable systems or system components (locks or mobile pump systems).
- Use of pump, fitted ad-on components, drive electronics, flanges and cables to climb onto the system.
- Removing, covering or obstructing warning notices.
- Operation outside of buildings.
- Standstill or storing of pump and drive electronics without suitable sealing and drying. When stored in a humid atmosphere corrosion can occur.
- Conversions, manipulations and maintenance work by persons not authorised by us.



Note:

Accessories which have not been specified by us may only be used after approval by us.

Technical data

4 Technical data

Table 1 Technical data

DRYVAC DV	650	650-r	800	800-r	Tolerance
Maximum pumping speed without gas ballast	650 m ³ /h		800 m ³ /h		± 5 %
Ultimate partial pressure					
Without purge gas or with purge gas for exhaust shaft seal purge	< 5 x 10 ⁻³ mbar				
With rotor purge	1 x 10 ⁻² mbar				± 10 %
With gas ballast	0.1 mbar				± 10 %
With purge gas for inlet shaft seal purge					
▪ (0.9 mm nozzle)	2.5 mbar				± 10 %
▪ (2.0 mm nozzle)	10.5 mbar				± 10 %
Maximum permissible inlet pressure	1050 mbar				
Maximum permissible discharge pressure	1200 mbar				
Integral leak rate	< 10 ⁻⁴ mbar l/s				
Water vapour tolerance with exhaust shaft seal purge gas and gas ballast	60 mbar > 20 N l/min				
Water vapour capacity	25 kg/h		30 kg/h		
Permissible ambient temperature	+5 to +50 °C		+5 to +45 °C		
Storage temperature	-20 to +60 °C				
Contamination grade with/without purge gas module	2/3		2		
Overvoltage category	3				
Noise level with silencer, at ultimate pressure (according to DIN EN ISO 2151)	67 dB(A)		70 dB(A)		KpA = 3dB
Noise level with rigid exhaust pipe, at ultimate pressure (according to DIN EN ISO 2151)	65 dB(A)		70 dB(A)		KpA = 3dB
Relative atmospheric humidity	95%, non-condensing				

Technical data

DRYVAC DV	650	650-r	800	800-r	Tolerance
Installation location	up to 2000 m (NHN)				
Cooling	Water				
Mains voltage ⁽¹⁾⁽²⁾	380-460 V or 200-240 V		380-460 V		± 10%
Frequency	50/60 Hz				± 5 %
Phases	3-phase				
Rated power	15 kW		19.6 kW		± 0.8 kW
Rated current	at 400 V - 31 A at 200 V - 60 A		38 A		
Motor efficiency class calculated and configured according to EN 60034-30	IE2		IE3		
Because of Frequency converter, in Eu corresponds to	IE3		-		
Power consumption at ultimate pressure	6.6 kW		7.5 kW		
Electrical power rating	17 kVA		23 kVA		
Mains fusing/characteristic	at 400 V - 32 A/C at 200 V - 63 A/C		50 A/C		
Short-circuit interrupting capacity ⁽³⁾	< 10 kA _{eff}				
Connectable cable cross-section, maximum	for 400 V - 16 mm ² for 200 V - 25 mm ²		16 mm ²		
Switching frequency of the frequency converter automatic switchover at low pump loads	2-15 kHz				
Speed	7200 RPM				
Minimum permissible speed ⁽⁴⁾	1200 RPM				
Protection class ⁽⁸⁾	IP 54	IP 55	IP 54	IP 55	
Lubricant filling	LVO 410 LVO 210		LVO 210		
Total lubricant quantity	1.2 l				± 5 %
Intake flange	DN 100 ISO-K / PN6 (1 on top, 2 on the sides)				

Technical data

DRYVAC DV	650	650-r	800	800-r	Tolerance	
Discharge flange	DN 63 ISO-K					
Materials						
components in contact with gas in the pump chamber	Grey cast iron/graphite cast iron/FKM/ steel/stainless steel/epoxy paint					
Materials sealing the pump off in the pump chamber towards the outside	FKM, grey cast iron					
Weight, approximate	590 kg	550 kg	590 kg	550 kg	± 20 kg	
Dimensions (L x W x H)	1280 x 570 x 420 mm	1200 x 450 x 400 mm	1290 x 570 x 420 mm	1200 x 450 x 400 mm	± 10 mm	
Water						
Water connection with cooling water unit	G1/2" (female)					
Water connection without cooling water unit	G1/4"					
Water temperature						
▪ Pumps with synthetic oil	5 °C – 35 °C ⁽⁶⁾					
▪ Pumps with PFPE	5 °C – 25 °C					
Minimum supply pressure	2 bar(g)** (unobstructed discharge, no backpressure)					
Maximum supply pressure	7 bar(g) ⁽⁷⁾					
Nominal flow	LVO 210 - 7.5 l/min LVO 410 - 10 l/min		10 l/min			
Purge gas						
Connection	plug-in connection D10					
Nominal setting pressure Purge gas (at nominal flow, valves open)	2.8 bar(g) ⁽⁷⁾					± 5 %
Permissible setting pressure Purge gas (at purge gas flow)	2.5 to 3.5 bar(g) ⁽⁷⁾					± 5 %
Permissible supply pressure Purge gas	4.0 to 10.0 bar(g) ⁽⁷⁾					± 5 %
Purge gas flow shaft seal / rotor	22 to 107 slm refer to Connect the purge gas on page 35					± 10 %
Maximum gas ballast flow (P _{inlet} < 10 mbar) ⁽⁵⁾	220 slm		280 slm			± 10 %

Technical data


- (1) In the case of mains voltage drops or interruptions (brownouts) up to two seconds, operation is maintained and no error message is output. For mains voltages over 460 V this duration may be shorter.
- (2) Mains power grids: TN Systems, TT systems (earthing at the star point). For other types of mains power grid, consult us.
- (3) The pump is not suited for electric circuits capable of delivering a current in excess of 10 kA (RMS) at maximum mains voltage.
- (4) The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than 1 hour can cause damage to the pump due to a lack of lubrication.
- (5) The gas ballast flow may vary due to different conditions. The gas ballast flow through the DV pump is much dependent on the inlet pressure.
- (6) At 460 V and higher, we recommend a maximum cooling water temperature of 25° C.
- (7) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- (8) All unused openings must be closed to reach the IP rating.

 **Note:**

The frequency converter standard ratings are valid for an installation altitude up to 1000 m.

If the altitude exceeds 1000 m both the input voltage and the rated output current must be derated for 1% per 100 m.

Figure 2. Permissible gas inlet temperature as function of the inlet pressure



1. Permissible range: under the curve.

For $50 \text{ mbar} \leq P_E \leq 500 \text{ mbar}$ applies:

$$T_e = -190 \cdot \lg(P_E) + 572.8 \text{ in } ^\circ\text{C}$$

P_E (mbar)	T_E (°C)
<50	250
50	250
75	217
100	193
125	174
150	159
200	136
250	117
300	102
350	89
400	79
450	69
500	60
>500	60

Transport

5 Transport



WARNING: SUSPENDED LOAD

Risk of injury and damage to equipment. Observe safety notes given in [Mechanical hazards](#) on page 11.

Crane eyes must not be interchanged with pumps. Only use the crane eyes specifically supplied with the respective pump.



Note:

The pumps are supplied filled with oil or PFPE. For this reason they should, while being transported or shipped, not be subjected to much tilting (10 degree maximum). Store the pumps only horizontally standing on their feet.

Refer to [Figure: Lifting the DRYVAC](#).

Lift the pump at the crane eyes. Use all crane eyes. The pump can also be transported with a fork lift. Make sure that it cannot tip over.

Pumps with castors


Due to the castors which have been fitted, the DRYVAC must only be installed on a levelled surface capable of carrying the weight of the pump as there exists the danger of the pump rolling away. The pump must also only be moved on levelled surfaces.

Moving the pump on slopes or ramps is not allowed.

The pump must only be transported using a fork lift or a crane.

At the installation site, use all four adjustable feet for aligning thereby securing the unit from rolling away and thus taking away the load from the castors.

Figure 3. Lifting the DRYVAC



1. Crane eyes (4 off)


6 Installation

6.1 Dimension drawings

Note:

All dimensions given are in mm (inch).

Figure 4. DRYVAC DV 650, DV 800




Note:

Purge gas or gas ballast valves and cooling water unit are not shown.

For CAD installation drawings in the STEP format, contact us or log in to our e-shop.

Installation


Figure 5. DRYVAC DV 650-r, DV 800-r



Note:

Figure: DRYVAC DV 650-r, DV 800-r is shown with cooling water unit (option) and with purge gas and gas ballast module.

Figure 6. Connections for the DRYVAC



- | | |
|---|---|
| 1. Inlet | 2. Optional intake flange (blanked off) |
| 3. Optional intake flange (blanked off) | 4. Purge gas supply |
| 5. Exhaust | 6. Cable entry frame |
| 7. Mains power supply | |

* Refer to [Figure: Cooling water connection](#) for versions without cooling water unit.

Note:

For purge gas, refer to [Figure: Triple purge gas module](#) and [Connect the purge gas](#) on page 35.

6.2 Placement

Place the pump system on a flat and levelled surface.

The pump is designed for operation in buildings.

We recommend to leave the crane eyes screwed in.

Pumps with castors and feet. For proper securing against rolling away, use all four adjustable feet for aligning thus taking away the load from the castors.

Remove covers and blank flanges on the pump just before fitting the pump so that the assembly work can be performed under the cleanest conditions.

Check whether there is any desiccant present in the intake area. If required remove it.

Fitting accessories

When planning to fit the accessory parts, roots pump adapter or non-return valve, first note the information given in [Mounting accessories](#) on page 56.

Oil level in the DRYVAC oil glasses


Refer to [Figure: Oil level in the DRYVAC oil glasses](#).

Installation

The pumps are supplied filled with synthetic oil or PFPE. Nothing will have to be refilled. Check the oil levels through all oil level glasses (2 per pumping stage).

If one of the oil levels is found to be incorrect, contact us.

Figure 7. Oil level in the DRYVAC oil glasses



1. Oil level glass

Table 2. Oil level during operation

Parameter	Maximum	Minimum
Gear side	-6 mm	-10 mm
Motor side	-3 mm	-7 mm



Note:

The oil level shown is applicable when the pump is at standstill.

Purge gas or gas ballast valves and cooling water unit are not shown.

6.3 Connect the intake and exhaust lines

6.3.1 Intake lines



WARNING: FAILURE OF BELLOWS

Risk of injury or damage to equipment. Align the bellows. Do not overstress the bellows. Too much stress on the bellows will cause premature failing of the bellows and thus leaks in the system.

Connect the intake line to the pump. We recommend using bellows on the top of the pump for vibration absorption.

Support the intake lines.

The intake lines must be clean.

Connect the intake flange either with intake screen and O-ring or with a centring ring without outer ring.


Installation

Upon delivery, the optional intake flanges at the side are only provided with an O-ring seal. This will be inadequate for the purpose of connecting an intake line.

 **Note:**

Make sure that no items like welding beads, bolts, nuts, washers, pieces of wire, for example, enter into the inlet. Observe safety information given in [Danger of pump damage](#) on page 16.

Figure 8. Intake flange connections



Purge gas or gas ballast valves are not shown.

1. Intake screen DN 100
2. O-ring 104.14 x 5.33 FPM 70 Shore A

You can also use centering ring with O-ring, DN 100 ISO-K, part number 88704 (stainless steel) (use without outer ring).

6.3.2 Exhaust lines



WARNING: LEAK TIGHTNESS

Risk of injury and damage to equipment. Check leak tightness of the exhaust lines on a regular basis. Observe safety information given in [Hazards caused by materials and substances](#) on page 14.

Observe safety information given in [Mechanical hazards](#) on page 11.

Always operate the pump with a connected exhaust line. The exhaust line must be designed for the specific kind of application. Lay permanent piping to the outside or connect it to a suitable exhaust gas abatement system.

Connect the exhaust line to an abatement system with sufficient throughput, if required by the process. The DRYVAC pumps will be switched off because of overpressure if the abatement system is too small.

Connect the exhaust lines to the pump system's exhaust connections. Use bellows to eliminate tension in the line.

Installation

The exhaust line should have the same or larger diameter than the exhaust flange and 2.0 mm minimum thickness.

The exhaust line must be able to withstand 1.3 bar and 150 °C.

Keep the exhaust line free of deposits. If the exhaust flow becomes restricted, deposits could collect in the DRYVACs. In order to prevent deposits in the exhaust lines it may be necessary to heat the exhaust lines.

Avoid connecting the pump system together with oil-sealed pumps to one central exhaust system. Using a common exhaust line could result in condensate back streaming into the DRYVAC or in dust adhering in the exhaust line.

Check leak tightness of the exhaust lines on a regular basis.



Note:

In the case of wet processes avoid the ingress of any liquid into the pump. Observe safety information given in [Danger of pump damage](#) on page 16.

6.4 Cooling water connection



CAUTION: SHOCK COOLING

Risk of crash. With the pump warm from operation do not suddenly supply very cold cooling water. There is the risk of a crash due to shock cooling.

Observe safety information given in [Thermal hazards](#) on page 13.

Refer to [Table: Cooling water data for the pump](#).

Connect the cooling water and make sure that the cooling water discharge is not constricted in any way. Select the lines in view of the temperatures and pressures which are to be expected.

Select a nominal width which is as wide as possible so as to avoid pressure losses especially for the discharge (flow velocity below 2 m/s).

The temperature of the discharged cooling water must not exceed 55 °C as otherwise the lines will tend to calcify.

Make sure cooling water flow is adequate in accordance with the technical data.

Cooling water data for the pump

Materials in the cooling circuit of the pump	AISI 304, red brass, brass, EPDM, epoxy paint
Feed pressure	2 – 7 bar(g)

Table 3 Cooling water data for the pump

Type	Power loss to be dissipated by the cooling water kW	Cooling water discharge temperature °C	Cooling water demand at feed temperature*			
			30 °C to 35 °C	25 °C to 30 °C	20 °C to 25 °C	5 °C to 20 °C
			l/min	l/min	l/min	l/min
DV 650 (LVO 210)	10.5	50	7.5	6.0	5.0	4.3
DV 650 (LVO 410)	10.5	45	-	-	8.0	7.0
DV 800 (LVO 210)	12	45	10.0	8.0	7.0	6.0

* It is possible to add 30% of glycol mixture to the operation of the cooling water circuit.

The addition of glycol reduces the specific heat capacity of the coolant mixture by approximately 7%. To ensure the comparable heat dissipation, the values in the table must be adjusted accordingly, and the flow must be increased, for example.

DRYVACs with cooling water unit

Refer to [Figure: Cooling water connection](#).

The DRYVAC pumps are equipped with a built-in pressure reducer. We recommend not to change the setting.

The DRYVAC pumps are equipped with a pressure relief valve. It prevents the water from boiling in the cooling circuit when the cooling water supply and drain are closed. The valve opens at 8 bar(g) and releases small amounts of water or vapour into the base pan.

DRYVACs without cooling water unit



WARNING: HOT SURFACE


Risk of injury or damage to the equipment. Observe the safety information given in [Thermal hazards](#) on page 13.

Refer to [Figure: Cooling water connection](#).

(Industrial versions) For these DRYVAC pumps do not connect the cooling water using self-sealing quick locks or shut off the feed and discharge lines with valves.

Installation

Figure 9. Cooling water connection



- A. DRYVAC with cooling water unit
- B. DRYVAC without cooling water unit

- 1. Pressure relief valve 8 bar(g)
- 2. Pressure regulator
- 3. Pressure gauge
- 4. Cooling water connectors
- 5. Cooling water - out
- 6. Cooling water - in

All DRYVAC versions

If work on the water cooling system becomes necessary and in the case of a longer standstill or transportation, completely drain out all cooling water and completely dry the lines (with nitrogen, for example).

Block or label the area of the cooling water and exhaust lines to prevent tripping.

6.4.1 Water quality

To make sure long trouble-free operation the cooling water must not contain any oils, greases and suspended solids. Moreover, we recommend compliance with the limit values given in [Table: Water quality](#).

Table 4. Water quality

Parameter	Value
Appearance	Clear, free of oils and greases
Suspended matter	< 250 mg/l
Particle size	< 150 µm
Electrical conductivity	< 700 µS/cm

Installation

Parameter	Value
pH value	7.0 to 9.0
Total hardness (total alkaline earths)	< 8 °dH
Aggressive carbon dioxide	None, not detectable
Chloride	< 100 mg/l
Sulphate	< 150 mg/l
Nitrate	≤ 50 mg/l
Iron	< 0.2 mg/l
Manganese	< 0.1 mg/l
Ammonium	< 1.0 mg/l
Free chlorine	< 0.2 mg/l



Note:

8 °dH (degrees German hardness) = 1.4 mmol/l

= 10 °e (degrees English hardness)

= 14 °f (degrees French hardness)

Deionized water can be used for cooling the pump, if the pH value corresponds to the range indicated above.

6.5 Connect the purge gas

The pump must be operated with purge gas. The purge gas is distributed in the pump via flow restrictors as follows:

- To the shaft seal on the motor side (inlet shaft seal purge)
- Into the pumping chamber (rotor purge)
- To the shaft seal on the gear side (exhaust shaft seal purge)

There are three versions of the purge gas module:

- At the triple purge gas module, the purge gas is supplied to the shaft seals on the motor side, the gear side and into the pumping chamber (rotor purge).
- At the double purge gas module, the purge gas supply protects the shaft seals on the motor side and the gear side.
- At the single purge gas module, the purge gas supply protects the shaft seals on the motor side. The second purge gas connection and the rotor purge are blank flanged.


The manifold block with valves, gauge and condensate separator is identical for the versions.

Connect nitrogen or air as purge gas. If in doubt, contact us.

Gas temperature	0 to +50 °C
Filter size	40 µm
Maximum condensate capacity	22 cm ³
Operating medium	Filtered, dry air or nitrogen of the quality class 5, free of oil, quality class 3 in accordance with ISO 8573-1, Filter mesh 40 µm


Installation

Figure 10. Triple purge gas module



- | | |
|---------------------------|------------------------------|
| 1. Solenoid valve SV40 | 2. Solenoid valve SV41 |
| 3. Rotor purge | 4. Solenoid valve SV42 |
| 5. Inlet shaft seal purge | 6. Purge gas supply |
| 7. Condensate vessel | 8. Pressure switch |
| 9. Pressure gauge | 10. Exhaust shaft seal purge |


Figure 11. Double purge gas module and 24 V gas ballast - version 1



- | | |
|---------------------------|------------------------------|
| 1. Solenoid valve SV40 | 2. Solenoid valve SV41 |
| 3. Solenoid valve SV42 | 4. Gas ballast |
| 5. Inlet shaft seal purge | 6. Purge gas supply |
| 7. Condensate vessel | 8. Pressure gauge |
| 9. Pressure switch | 10. Exhaust shaft seal purge |


Installation

Figure 12. Double purge gas module and 24 V gas ballast - version 2



- | | |
|-----------------------------|------------------------|
| 1. Solenoid valve SV41 | 2. Solenoid valve SV40 |
| 3. Gas ballast | 4. Solenoid valve SV42 |
| 5. Inlet shaft seal purge | 6. Purge gas supply |
| 7. Pressure gauge | 8. Pressure switch |
| 9. Exhaust shaft seal purge | |


Figure 13. Double purge gas module



- | | |
|-----------------------------|------------------------|
| 1. Solenoid valve SV40 | 2. Solenoid valve SV42 |
| 3. Inlet shaft seal purge | 4. Purge gas supply |
| 5. Pressure gauge | 6. Pressure switch |
| 7. Exhaust shaft seal purge | |

Installation


Figure 14. Single purge gas module



- | | |
|------------------------|-----------------------------|
| 1. Solenoid valve SV40 | 2. Purge gas supply |
| 3. Condensate vessel | 4. Pressure gauge |
| 5. Pressure switch | 6. Exhaust shaft seal purge |

Details for the purge gas module

Nozzle/Check valve



The nozzles can be changed according to the application. As standard, the S and C versions of the DRYVAC are equipped with 0.9 mm nozzles for the shaft seals and a 1.0 mm nozzle for the rotor purge.

The process industry versions (operating agent: LVO 210) of the DRYVAC are equipped as standard with a 0.9 mm nozzle for the exhaust shaft seal and a 2.0 mm nozzle for the inlet shaft seal (for ensuring a sufficient purge during venting). Here the rotor purge is ambient air gas ballast.

Installation

Gauge setting	Nozzle diameter						
	0.2 mm	0.9 mm	1.0 mm	1.2 mm	1.5 mm	1.7 mm	2.0 mm
bar	slm	slm	slm	slm	slm	slm	slm
2.8	1	22	28	38	60	74	92
3	1	23	30	41	63	78	97
3.5	2	26	33	46	70	86	107

Range	Parameter
(Red) -1 to 2.0 bar	Pressure and flow too low
(Green) 2.5 to 3.5 bar	recommended range
(Red) 4.5 to 9.0 bar	Pressure too high. Regulator valve cannot open against the pressure

The pump must be vented, but only up to atmospheric pressure.

Make sure that the purge gas flow is not obstructed.

The purge gas supply should not be shut off while the pump system is operating, above all especially not during shutdown and venting operations.

Wetted materials: Brass, aluminium, zinc, polycarbonate, polybuteneterephthalate (PBT), NBR, polyamide tube, copper, stainless steel, PTFE, Loctite.

The pressure reducer is set to 2.8 bar at nominal flow (valves open) on delivery.

See [Electrical connection DRYVAC DV 650 and DV 800](#) on page 51 and [Electrical connections DRYVAC DV 650-r and DV 800-r](#) on page 53 for the connection of the pressure switch and the solenoid valves.

6.5.1 Gas ballast valve


Only for some versions, see [Ordering information](#) on page 88, or option.

The gas ballast valve is of the electropneumatically operated type. Here the gas (compressed air or nitrogen) from the valve block is used to actuate the electropneumatic gas ballast valve. The valve needs a pressure of 3.0 bar.

The actual ballast gas will generally be ambient air.


Installation

Figure 15. Electropneumatic gas ballast valve (option)



1. Gas inlet for gas ballast control valve and the seal on the exhaust side
2. Air filter for gas ballast inlet
3. Pilot valve for gas ballast

Figure 16. Double purge gas module with gas ballast valve (top view)



1. Air filter for gas ballast inlet
2. Gas ballast valve

6.5.2 Guidelines for purge gas operation, settings and monitoring



CAUTION: AIR PURGE

Risk of injury or damage to equipment. The safety always has to be considered (be careful with air purges and read our safety booklet).



Note:

Possible purge gases are N₂ and Compressed Dry Air (CDA) only.
Exhaust shaft seal purge is running in most of all applications all the time.

Installation

Rotor purge

- In most cases not used all the time, often active in specific process steps.
- Used for light gas performance, dilution to avoid condensation, dilution to reduce chemical reaction and dilution to dilute below flammability limits.
- Applying up to 33 slm purge gas (1.0 mm nozzle) to the rotor purge position on DV 650 results in: $p_{\text{end}} < 1 \times 10^{-2}$ mbar for air or N₂.

Exhaust shaft seal purge

The exhaust shaft seal purge is the most important purge position of the pump to protect the pump from process materials and to keep it dry and clean. The exhaust shaft seal purge protects the motor area (piston ring shaft seal, bearings, motor) against particles/dust and condensable gases like water or others. This purge is always recommended and there are only a few applications possible where one can stop exhaust shaft seal purge flow.

Gas types: Air (consider safety concerning flammable gases), nitrogen.

- Exhaust shaft seal purge is running in 99% of all applications at all time.
- Open exhaust shaft seal purge when starting the pump and stop it after the pump has stopped.
- In many cases it might be better to keep the exhaust shaft seal purge on for 15 to 30 minutes after stopping the pump. This cleans and dries out the exhaust.
- If you want to operate without exhaust shaft seal purge contact our technical support.
- The exhaust purge gas does not reduce the pump performance in any way.

Gas ballast

- Used for dilution by ambient air to avoid condensation, for drying out the pump, dilution to reduce chemical reaction or to transport small amounts of dust to the exhaust.
- The maximum gas ballast flow ($p_{\text{inlet}} < 10$ mbar):

DV 800	280 slm
DV 650	220 slm

- The gas ballast flow is not constant under all conditions.
- The gas ballast flow of the DV pumps is strongly depending on the inlet pressure.
- Applying maximum gas ballast flow results in: $p_{\text{end}} \geq 1 \times 10^{-1}$ mbar for air.

Inlet shaft seal purge

The process industry pumps (all pumps which have LVO210 as lubricant) are equipped with a 2.0 mm nozzle – this provides ~ 90 slm of gas flow.

Note:

If there is a risk, that in the application condensable gases or solids can be transported into the gearbox area, it is a must to use inlet side venting purge to protect the DRYVAC pump.

- A. Contamination during pump down or fast pressure rise

Installation

- For fast pressure rises the 2.0 mm nozzle has to be used on the inlet side.
 - Activate flow (solenoid valve) 2 seconds before pressure rise.
 - Stop flow when the inlet pressure drops below 100 mbar.
 - If you have only the 0.9 mm nozzle installed (2.0 mm recommended) activate flow 2 seconds before pump down and stop the flow when the pressure drops below 20 mbar.
- B. Contamination during chamber vent
- To avoid contamination during chamber venting, the inlet shaft seal purge should be activated at all time during the chamber venting.
- C. Contamination during continuous operation
- Use the 2.0 mm nozzle in combination with the solenoid valve (customer controlled) to protect against fast pressure rises.
 - Use the smaller nozzle to allow a continuous flow of gas at all time (constant flow).
 - If a constant flow is not possible you can try to control the small flow (0.9 mm nozzle) as well, for example with pressure rises and ventilation.


With the accessory "Permanent inlet purge kit", the inlet side of the DRYVAC pump may be protected against being contaminated. This is effected by a permanent, comparatively small purge flow (0.5 slm). For this, the permanent inlet purge kit is so connected that it is always opened when also the purge gas on the exhaust side (motor side) of the pump is open; for example generally always when the DRYVAC being switched on.

Pressure switch: To monitor purge gas availability

The shut-off threshold of the pressure switch PSL220 is 2.4 bar(g). This switch (refer [Figure: Triple purge gas module](#)) is located in between pressure regulator and the solenoid valves. This switch is always installed, but the signal is not controlled by the pump itself (frequency converter). An LED indicates the status on the device itself. A to be connected Programmable Logic Controller (PLC) or junction box is needed to monitor this signal.

Installation

Figure 17. Purge gas and switches schematic



Note:

At pumps with single purge gas module check valves CV-81 and CV-82 and the corresponding throttles are missing, the lines are blanked off.

No.	Designation	Description
1	TSH 281	Temperature Switch High Frequency Converter Internal
2	PSH 200	Pressure switch high Exhaust line (19 pump outlet)
3	LI 320	Level Indicator Oil Motor Bearing
4	Process in	Pump inlet
5	LI 321	Level Indicator Oil Gear Side
6	TSH 280	Temperature Switch High Pt 1000 Gear Flange
7	SRV 100	Safety Relief Valve 8 bar(g)
8	Cooling water out	-
9	Cooling water in	-
10	PI180	Pressure indicator Water
11	SV44	Solenoid Valve Optional flushing
12	-	Purge gas N ₂ 4 - 8 bar
13	PI181	Pressure indicator Nitrogen
14	SV43	Solenoid Valve Optional purge
15	SV42	Solenoid Valve Inlet shaft seal purge*

Installation

No.	Designation	Description
16	SV41	Solenoid Valve Rotor purge*
17	SV40	Solenoid Valve Exhaust shaft seal purge
18	PSL 220	Pressure Switch Low Purge 2.4 bar(g)
19	Out	Pump outlet
20	TSH 285	Temperature Switch High Temperature limiter Motor housing
-	PRV140 PRV141	Pressure Regulator (Filter)
-	CV80 CV81 CV82	Check valve

* Opening of these valves will impair the ultimate pressure, refer [Technical data](#) on page 21.

6.6 Electrical connection

WARNING: ELECTRICAL HAZARD

Risk of injury or damage to equipment. Observe safety information given in [Electrical hazards](#) on page 12.



Take note of the information provided in the operating instructions enclosed with the frequency converter. Read these operating instructions and make yourself comfortable with the contents before installing and operating the frequency converter or before doing maintenance work on it. The frequency converter must be installed in agreement with the information given in these operating instructions and in agreement with the locally applicable regulations. Non-compliance with the safety information can result in severe or even deadly injuries or may damage the products or facilities and systems operated in connection with the product.

Wiring the main circuit input

Consider the following precautions for the main circuit input.

- Use fuses recommended in main circuit only, refer [Technical data](#) on page 21.
- If using a ground fault circuit breaker, make sure that it can detect both d.c. and high frequency current.

Ground connection

Take the following precautions when grounding the frequency converter.

- Always connect the frequency converter to ground in accordance with the international and local regulations for equipment exhibiting an increased leakage current.
- Keep the ground wires as short as possible. The frequency converter produces leakage currents (typically less than 10 mA). In the case of unbalanced mains power supplies, the leakage current may exceed 10 mA. In this case the protective ground conductor must exhibit a cross-section of at least 10 mm² or connect a further protective ground conductor having at least the same cross-section as the connection

Installation

cable. A connection point is provided, refer [Figure: Establishing the potential equalisation at the pump casing](#).

- When using more than one frequency converter, do not loop the ground wire.
- For compliance with IEC 61010-1 it is mandatory to connect the additional protective earth conductor.

Electromagnetic Compatibility (EMC)

By maintaining the operational conditions specified this product complies with the EMC emission limits for industrial production environments. For 200 V, refer to the EMC filter manual (Publication number - 301140450).



Note:

The frequency converter may, when deployed in residential areas, cause high-frequency interference. In such a case the operator of the unit will have to introduce additional measures for the purpose of suppressing high-frequency interferences. All openings at the feed through that are not used must be closed.

EMC filter



WARNING: EMC FILTER SWITCH

Risk of serious injuries or death. Ground the neutral point on the power supply to comply with the EMC Directive before turning on the EMC filter or if there is high resistance grounding.




CAUTION: NON-GROUNDING NETWORK

Risk of damage to the equipment. When using a drive with a non-grounding network, high resistance grounding or asymmetric grounding network, place the screw for the EMC filter switch in the OFF position and disable the built-in EMC filter. Failure to comply could cause damage to the drive.

The drive has a built-in EMC filter. It is delivered with EMC Filter active for internal FC and deactivated for external FC. On the drive, move the screw position to switch ON (enable) and OFF (disable) the EMC filter. Make sure that the symmetric grounding network is applied when you install the screw in the ON position to enable the built-in EMC filter in compliance with the EMC Directive.





For 200 V, the internal filter does not comply with the requirements of EN61000-6-4. Connect the external filter in compliance with the EMC directive. When you connect the external filter make sure to deactivate the internal filter.

Figure 18. Symmetric grounding



Installation

Table 5. Asymmetric grounding

Type of grounding	Diagram
Grounded at the corner of the delta connection	
Grounded at the middle of the side	
Single-phase, grounded at the end point	
Three-phase variable transformer without solidly grounded neutral	

The screw size of the EMC switch is M4 x 20 with tightening torque 1.0 - 1.3 Nm.

6.6.1 Electrical schematic

Control circuit wiring

The control terminal board is equipped with screwless terminals. Always use wires within the specification listed below. For safe wiring it is recommended to use solid wires or flexible wires with ferrules. The stripping length respectively ferrule length should be 8 mm.

Installation


Wire type	Wire size (mm ²)
Solid	0.25 to 1.5
Flexible	0.2 to 1.0
Flexible with ferrule	0.25 to 0.5

Control circuit wiring precautions

Consider the following precautions for wiring the control circuits:


- Separate control circuit wiring from main circuit wiring and other high-power lines.
- For external control power supply use a UL Listed Class 2 power supply.
- Use twisted-pair or shielded twisted-pair cables for control circuits to prevent operating faults.
- Ground the cable shields with the maximum contact area of the shield and ground.
- Cable shields should be grounded on both cable ends.
- If flexible wires with ferrules are connected they might fit tightly into the terminals. To disconnect them, grasp the wire end with a pair of pliers, release the terminal using a straight-edge screw driver, turn the wire for about 45°, and pull it gently out of the terminal.

Table 6 Main circuit terminals

Terminal	Type	Function
R/L1, S/L2, T/L3	Main circuit power supply input	Connects line power to the frequency converter via line filter.
U/T1, V/T2, W/T3	Drive output	Connects to the motor.
B1, B2	Braking resistor	For connecting an optional braking resistor
+1, +2	d.c. reactor connection	Linked at shipment. Remove the link to install a d.c. choke.
+1 –	d.c. power supply input	For connecting a d.c. power supply.
 (2 terminals)	Ground terminal	For 200 V class: Ground with 100 Ω or less For 400 V class: Ground with 10 Ω or less

Installation

Figure 19. Mains and control circuit wiring DRYVAC



*External EMC filter for 200 V.



Note:

< 1 > Connected using sequence input signal (S1 to S7) from NPN transistor.
Default: sink mode (0V com).

< 2 > Use only the +24 V internal power supply in sinking mode.

The source mode requires an external power supply.

Switch	Function	Input
DIP S1	I/V	Amper/Voltage
DIP S2	ON/OFF	Memobus
DIP S4	P/M	PTC/A2

DIP switch S4 changes the functionality of analog input A2. When DIP switch S4 is set to P the function is PTC input. When DIP switch S4 is set to M the function of analog input A2 is multi-function input.


Control with I/Os

Refer to [Figure: Control I/Os](#).

Installation

The DRYVAC can be controlled via digital inputs and outputs. To do so, change the parameter b1-02 from 0 (RUN and STOP buttons) to 1 (digital inputs), see [Field-bus interface](#) on page 59.

Figure 20. Control I/Os



Note:

TB = Terminal Block

Use the 5-conductor connector at the SN clamp.

Refer [Option: Change the speed of the pump](#) on page 66 for 2nd frequency.

Start/stop connection

Bridge SN and S1 to start the DRYVAC. The run-up time to nominal speed (120 Hz) amounts to 200 seconds. Open SN and S1 to stop the DRYVAC.

Connect SN with S4 to reset an error message. Reset will not function as long as the error message is active. In addition, the start signal must be set to “0” before the reset.

To set a 2nd frequency refer [Option: Change the speed of the pump](#) on page 66.

The SN (earth) terminal in the frequency converter is already occupied by a ferrule. If you wish to control the pump per I/Os, use the supplied 5-conductor connector to ground the I/Os and the pump sensors on the I/O board of the frequency converter.

The 5-conductor connector is connected to SN and sensors.

Sensors


The exhaust pressure switch (setpoint 1.25 bar = 0.25 bar(g)) is connected to S2 and SN.

The pump’s temperature sensor is connected to A1, AC and +V.

The temperature limiter is connected to S3 and SN.

Installation

Figure 21. Circuit diagram for the purge gas pressure switch



Signal	Pin
UB (24 V d.c. maximum 30 mA)	1
S1	4

Connect the purge gas module electrically

Refer to [Figure: Circuit diagram for the purge gas pressure switch](#).

Connect the purge gas pressure switch and solenoid valves to your system control.

Connect the solenoid coils for the purge gas valves to your system control. The plugs are on the coils on delivery.


Table 7. Data for the solenoid coils

Parameter	Value
Voltage	24 V d.c.
Power consumption	8 W
Type of protection (DIN 40050)	IP 65
Cable screw connection	Pg 9

MEMOBUS/Modbus

The frequency converter is equipped with a serial RS 485 interface with MEMOBUS/Modbus (RTU) protocol. To active the MEMOBUS, the DIP S2 must be set to ON. Further details are available on request.

Figure 22. Option: Wiring with external power supply



* For settings see parameter

Remove the jumper from the MFDI terminals. It is not necessary to close the circuit between terminals SC-SP and terminals SC-SN.

6.6.2 Electrical connection DRYVAC DV 650 and DV 800

Connect the terminals as shown in [Figure: Control I/Os](#).

Connect the solenoid coils for the purge gas valves and the purge gas pressure switch to your system control. The plugs are on the coils on delivery.

Mains connection


Remove the cover from the frequency converter. The cover is connected to the PE terminals with a PE cable. Do not interrupt this cable.

Connect the mains cable as shown in [Figure: Frequency converter without covers](#). Use the M32 cable fitting for that purpose. The terminals are designed for 16 mm² maximum cable diameter.

Remount the cover on the frequency converter after the cable connections.

Installation

Figure 23. Frequency converter without covers




- | | |
|--|-------------------------------------|
| 1. Exhaust pressure pipe | 2. Feedthrough for mains connection |
| 3. Genius (IoT) kit | 4. Power supply kit |
| 5. Exhaust pressure switch
(0.2 bar(g)) connector (internally
connected to the frequency
converter) | 6. Frequency converter |
| 7. L1 | 8. L2 |
| 9. L3 | 10. PE |
| 11. Pt 1000 connection | |

Establishing potential equalisation

An M6 thread is provided at the motor housing for connecting the external potential equalisation cable.

Connect the potential equalisation conductor as depicted in [Figure: Establishing the potential equalisation at the pump casing](#).

Figure 24. Establishing the potential equalisation at the pump casing



- | | |
|--|----------------------------|
| 1. Copper strap (for example) | 2. Washer |
| 3. Elastic element to counteract settlements | 4. Hexagon socket screw M6 |

6.6.3 Electrical connections DRYVAC DV 650-r and DV 800-r

The external frequency converters comply with EMC guidelines when the cable between pump and frequency converter does not exceed a length of 20 m maximum. Longer cables are possible but at the risk of possibility exceeding EMC limits.

The maximum current load at the frequency converter output is 38 A.

Connect the main and control circuits as shown in [Figure: Main and control circuit wiring](#).

Check the direction of rotation

Check the direction of rotation after connection. To do so, open the intake.

Switch on the pump and switch it off immediately. The rotors shall move upwards in the middle and shall move down at the sides.

Start/stop connection

Bridge SN and S1 to start the DRYVAC. The run-up time to nominal speed (120 Hz) amounts to 200 seconds. Open SN and S1 to stop the DRYVAC.

Sensors

See [Figure: Main and control circuit wiring](#).


Use the 5-conductor connector at the SN clamp.

Connect the exhaust pressure switch (setpoint 1.25 bar = 0.25 bar(g)) to S2 and SN. A mating connector is delivered for the exhaust pressure switch.

Connect the temperature limiter to S3 and SN.

Installation

Figure 25. Main and control circuit wiring



*External EMC filter for 200 V.



Note:

TB = Terminal Block

The Pt 1000 cable (30 m) is delivered separately, so that it does not get damaged during transport. Unscrew the bolt with washer in the pump, place the Pt 1000 cable lug on the pump and screw in the bolt with washer with a torque of 10 ± 1 Nm.

The pump is delivered with a resistor, short cable and electrical distributor clamp.

- Connect the pump's temperature sensor (Pt 1000) to AC and the clamp.
- Connect the short cable to the clamp and A1.
- Connect the resistor to +V and the clamp.

Direct mains power connection



WARNING: DANGEROUS VOLTAGE

Risk of injury. Unplug any connectors only when the mains voltage is switched off and the pump does no longer turn.


Observe safety information given in *Electrical hazards* on page 12.

Connect the pump to the correct mains voltage through the connections provided in the junction box (refer to *Figure: Junction box of DRYVAC*).

The motor of the DRYVAC is equipped with a temperature dependent resistor (PTC).

Connect the PTC so that the pump is reliably shutdown when being thermally overloaded.

Figure 26. Junction box of DRYVAC



1/2 - Connections for the temperature switch

L1/L2/L3 - Power connection

6.7 Leak search after installation

Observe safety information given in *Hazards caused by materials and substances* on page 14.

On delivery, the pump is leak tight to 10^{-4} mbar·l/s (integral, leak-checked).

Leak-check all relevant connections after having installed the pump.

Installation

6.8 Mounting accessories

6.8.1 Roots pump adapter

CAUTION: SUSPENDED LOAD



Risk of injury and damage to equipment. The eye-bolts at the RUVAC must not be used to lift the pump combination.

When transporting, the DRVAC and the RUVAC need to be separated for safety reasons and reassembled at the new destination.

Refer to [Figure: Roots pump adapters](#).


The adapters serve as a connecting component when fitting a Roots vacuum pump onto the DRVAC DV 650.

The adapter mounting is described in the corresponding operating instructions.

After fitting, we recommend running of a leak search.

Exception: The WH 2500 can be lifted at its 4 eye-bolts together with the DRVAC if no other accessories are fitted.

Figure 27. Roots pump adapters



A. RUVAC 700
C. RUVAC 2500

B. RUVAC 2001
D. RUVAC 4400/7000

6.8.2 Non-return valve

CAUTION: NON-RETURN VALVE



Risk of injury or damage to equipment. Note the safety information provided in [Mechanical hazards](#) on page 11, [Thermal hazards](#) on page 13 and [Hazards caused by materials and substances](#) on page 14.

Refer to [Figure: Non-return valve](#).

Installation

The non-return valve is a fitting for shutting off which is fitted to the exhaust flange of the DRYVAC. It prevents gas from flowing back into the pump.

With the pump running, the non-return valve opens more or less wide depending on the gas flow. When the pump is switched off, the non-return valve closes automatically.

Supplied equipment: Non-return valve complete with O-ring and four M8 mounting bolts.

Installation


Only for non-return valve 112005A15 with swivel joint

Supplied equipment: Non-return valve complete with O-ring and four M8 mounting bolts.

Note the installation position for the non-return valve, see [Figure: Side view/sectional view of the non-return valve](#). The swivel joint of the valve must be located at the top. The valves must open in the direction of the gas flow.


Make sure that the O-ring sits in its groove. Bolt the non-return valve to the exhaust of the DRYVAC using the four M8 mounting bolts, tightening torque 25 ± 2.5 Nm.

Figure 28. Non-return valve 112005A15 with swivel joint




Installation

Figure 29. Side view/sectional view of the non-return valve with swivel joint



- | | |
|----------------------|-----------------|
| 1. M8 mounting bolts | 2. O-ring |
| 3. Swivel joint | 4. Exhaust line |
| 5. DRYVAC | |

Figure 30. Non-return valve 112005A14 for DRYVAC DV 650/800



Only for non-return valve 112005A14 for DRYVAC DV 650/800

Supplied equipment: Non-return valve complete with mounting equipment, e.g. O-rings and claws.

Note the installation position for the non-return valve, refer [Figure: Non-return valve 112005A14 for DRYVAC DV 650/800](#). The valve must open in the direction of the gas flow. Observe the arrow on the check valve. The lock screws should be positioned at the top so that no condensate can collect in the holes.

Operation

Proper operation of the non-return valve is only ensured in connection with clean processes. Operation of the valve needs to be checked regularly depending on the type of application.

7 Operation



WARNING: NOISE HAZARD

Risk of injury. Observe the safety information given in [Noise hazard](#) on page 15. Take suitable hearing protection measures.

7.1 Media compatibility

Refer [Conforming use](#) on page 19. For a list of materials in contact with the process gas, refer [Technical data](#) on page 21. If you use the system on an application for which it is not suitable, you may invalidate your warranties. If in doubt, contact us.

7.2 Field-bus interface

For installation and operation of the optional bus interfaces, please refer to the instructions of YASKAWA enclosed with the module.

For operating instructions regarding Field-bus interfaces, refer to the bus interface manual (Publication number - 301076031).

7.3 Start-up



WARNING: EXPLOSION HAZARD

Risk of explosion. In processes, where the process gases or by-products react with air, there is a risk of reactions like explosions. Purge the pump with nitrogen at every start-up before opening it to the process. This reduces the risk of reactions when the process gases come into contact with remaining oxygen in the pump.



WARNING: HOT SURFACE

Risk of hot surface. Observe the safety information given in [Thermal hazards](#) on page 13.

Do the checks before every start-up as follows:

- If the pump system is leak tight.
- Close all protective covers.
- Open the exhaust lines.
- Open the purge gas supply if connected.
- Open the cooling water return and supply.
- Switch on the main switches.
- Check messages on the frequency converter display.

Start the pump. The DV 650 is ready for operation after 5 minutes, the DV 800 after 10 minutes.

Dry the pump, if required by the process. To do so turn on the pumping system. Run the pumping system at ultimate vacuum for 60 minutes with a dry nitrogen shaft seal purge before you open it to the process.

Operation

7.4 Pump control connections

Depending on the connection, the pumps are operated through the remote control or the Field-bus. For the information about remote control connections refer to the [Electrical connection](#) on page 44, and for the information of Field-bus, refer to [Field-bus interface](#) on page 59.

In the event of a power failure, the pump will continue to operate up to 2 seconds without showing an error message.

For troubleshooting and testing, the frequency converter is equipped with LEDs and keys.

For pumps with IoT: To troubleshoot and test the frequency converter put the Display with the key and LEDs on.

Some parameters are only taken over after a restart.

7.4.1 LED operator and keys

After switching on, the display shows the output frequency in the delivery state (U1-02). The Pt1000 temperature can be read out in U8-08 or 07-03

For DV 650 and DV 800

The display shows the output frequency in the delivery state (U1-02). The Pt1000 temperature can be read out in U8-08 or 07-03.

Figure 31. LED operator
















Table 8 Keys and functions

Display	Name	Function
	Data display area	Displays the parameter, errors and other data
	RUN key	Starts the drive in the LOCAL* mode, if control is set to LOCAL.

Operation

Display	Name	Function
	STOP key	Stops drive. Uses a stop-priority circuit. This will also apply when a Run command (REMOTE Mode) is active at an external Run command source. To disable STOP priority, set o2-02 = 0 [STOP Key Function Selection = Disabled].
	LO/RE selection key	Switches drive control between the operator (LOCAL) and the control circuit terminals (REMOTE)*. The LED is on when the drive is in the LOCAL mode (operation from keypad).
	ALM LED light	Flashing: The drive is in the alarm state. On: The drive is in a fault state and the output is stopped.
	DRV LED light	On: The drive is ready to operate the motor. Off: The drive is in the Verify, Setup, Parameter Setting or Auto tuning mode.
	RUN LED light	Illuminated: The drive is in normal operation. OFF: The drive is stopped. Flashing: The drive is decelerating to stop. The drive received a Run command, but the frequency reference is 0 Hz. Flashing quickly: <ul style="list-style-type: none"> When the drive is in LOCAL Mode, the drive received a Run command from the MFDI terminals and is switched to REMOTE Mode. The drive received a Run command from the MFDI terminals when the drive is not in Drive Mode. The drive received a Fast Stop command. The safety function shut off the drive output. The user pushed STOP on the keypad while the drive is operating in REMOTE Mode. The drive is energised with an active Run command and b1-17 = 0 [Run Command at Power Up = Disregard Existing RUN Command].
	ESC key	Returns to the previous menu. Push and hold to go back to the frequency reference screen (the initial screen).
	Left arrow key	Moves the cursor to the left.
	Up/Down arrow key	Scrolls up/down to select parameter numbers, setting values, etc.
	Right arrow key (RESET)	Moves the cursor to the right. Resets a fault.

Operation

Display	Name	Function
	ENTER key	Selects modes, parameters and is used to store settings.
	REV LED	On: The motor rotation direction is reverse Off: The motor rotation direction is forward
	DWEZ LED	On: The drive is In DriveWorksEZ operation.

* The pump is not intended for LOCAL mode. Default mode is REMOTE

7.4.2 Power on



CAUTION: OPERATION SAFETY

Risk of damage to the equipment. The pre-set limiting parameters, in particular the maximum speed, must not be changed. Observe the safety information given in [Electrical hazards](#) on page 12.

Before you turn the power supply on make sure that:

- All wires are connected properly.
- No screws, loose wire ends or tools are left in the frequency converter.

After you turn the power on, the frequency converter mode display should appear and no fault or alarm should be displayed.

Refer to [Electrical connection](#) on page 44, connect S1 to SN, to start.

The frequency converter is programmed for this pump. The parameter access is limited. The default output frequency can be changed in the programming mode between 0 Hz and 120 Hz.

Description	Parameter in programming mode	Setting
Standard output frequency reference	d1-01	120 Hz

Note:

Do not run any auto-tuning on the frequency converter, since the pre-set motor parameters are then lost.

7.4.3 Frequency converter outputs

The frequency converter outputs have been assigned as follows:



Operation

P1-C1	Digital output Multifunction opto-coupler 48 V d.c. maximum 50 mA maximum	Contact closed during Warning (general message)
P2-C2	Digital output Multifunction opto-coupler 48 V d.c. maximum 50 mA maximum	Contact closed during Error (general message)
MA-MC	Relay output maximum AC 250 V 1A maximum DV 30 V 1A minimum 5 V 10 mA	Contact closed when pump is on target speed


Monitor parameter

The [Table: Monitor parameter](#) shows the the most important monitoring parameters about the frequency converter status and faults (monitoring mode).

Table 9. Monitor parameter

Monitor	Description
U1-01	Frequency reference (Hz)
U1-02	Output frequency (Hz)
U1-03	Output current (A)
U1-05	Motor speed (Hz)
U1-06	Output voltage reference (V a.c.)
U1-07	DC bus voltage (V d.c.)
U1-08	Output power (kW)
U1-09	Torque reference (% of motor rated torque)
U1-10	Input terminal status 
U1-11	Output terminal status 

Operation

Monitor	Description
U1-12	Drive status  <ul style="list-style-type: none"> 1: During run 1: During zero-speed 1: During REV 1: During fault reset signal input 1: During speed agree 1: Drive ready 1: During alarm detection 1: During fault detection
U1-13	Terminal A1 input level
U1-14	Terminal A2 input level
U1-16	Soft starter output (frequency after acceleration/deceleration ramps)
U1-18	OPE fault parameter
U1-24	Pulse input frequency
U7-03	Pump temperature
U7-04	Actual current limit
U7-05	Base block counter
Fault trace	
U2-01	Current fault
U2-02	Previous fault
U2-03	Frequency reference at previous fault
U2-04	Output frequency at previous fault
U2-05	Output current at previous fault
U2-06	Motor speed at previous fault
U2-07	Output voltage at previous fault
U2-08	DC bus voltage at previous fault
U2-09	Output power at previous fault
U2-10	Torque reference at previous fault
U2-11	Input terminal status at previous fault
U2-12	Output terminal status at previous fault
U2-13	Drive operation status at previous fault
U2-14	Cumulative operation time at previous fault
U2-15	Soft starter speed reference at previous fault
U2-16	Motor q-axis current at previous fault
U2-17	Motor d-axis current at previous fault
Fault history	
U3-01 to U3-10	Lists the 10 most recent faults
U3-11 to U3-20	Operation times that belong to the tenth most recent faults

* The faults CPF00, 01, 02, 03, UV1, and UV2 are not recorded in the error log.

7.4.4 Relay option board

Figure 32. Relay option board - Connections





Table 10. Terminal block

Symbol	PIN No.	Function
TB1	1A	K1 Output, Normally Open (NO) contact
	1B	K1 Output, Normally Closed (NC) contact
	1C	K1 Output, Common
TB2	2A	K2 Output, Normally Open (NO) contact
	2B	K2 Output, Normally Closed (NC) contact
	2C	K2 Output, Common
TB3	3A	K3 Output, Normally Open (NO) contact
	3B	K3 Output, Normally Closed (NC) contact
	3C	K3 Output, Common
TB4	K1	K1 control signal
	K2	K2 control signal
	K3	K3 control signal
	KC	Common for K1, K2 and K3

Operation

Figure 33. Set the second set point frequency



A. Switch (normally open)

B. Pump run-up with two set up frequencies (schematic)

7.4.5 Option: Change the speed of the pump



WARNING: ELECTRICAL CONNECTIONS

Risk of injury. Connections must only be provided by a trained person. Please note the national regulations in the country of use as, for example, in Europe EN 50110-1. We recommend to consult us first.

The frequency converter permits to:

- enter a second setpoint frequency and select it as required. This allows gentle running up of the pump for a sensitive vacuum chamber, for example.
- change the speed of the pump through an input at the analogue input.

Note:

Do not operate the pump for more than one hour at frequencies less than 20 Hz.

Enter the desired second frequency through the parameter d1-03 (default 0 Hz, allowed input range 0 Hz to 120 Hz). Closing of the switch between the digital input S5 and SN will enable the second frequency.

The input signal at S5 can be controlled through a timer relay or through the PLC.

Control the speed through a voltage input

Set parameter b1-01 to 1 (0 default). Through this, the analogue input terminal A2 becomes the main frequency reference.

Set DIP switch S1 to the bottom position V (voltage).

Set parameter H3-09 to 0. Through this, the input signal type is set to "0-10 V d.c. with lower limit". Make sure that parameter H3-10 has been set to the default value 0.

Connect the control voltage to terminals A2 and AC. 0 to 10 V, 0 V corresponds to 0 Hz, 10 V corresponds to 120 Hz, linear increase.

Control the speed through a current input

Set parameter b1-01 to 1 (0 default). Through this, the analogue input terminal A2 becomes the main frequency reference.


DIP switch S1 must be at its default position: top, position I.

DIP switch S2 must be in off position.

Parameter H3-09 must be at its default value 2, input signal type “4-20 mA”. Make sure that parameter H3-10 has been set to the default value 0.

Connect the control current to terminals A2 and AC. 4 to 20 mA, 4 mA corresponds to 0 Hz, 20 mA corresponds to 120 Hz, linear increase.

Figure 34. Control the pump speed



A. Controlling the speed through a voltage or current input

B. DIP switch position on the frequency converter board of the pump

Table 11 Warning and shut-off thresholds

Parameter	Designation	Warning threshold	Shut-off threshold	Processing by	Fault display
Exhaust pressure (Pressure difference to ambient pressure)	PSH 200		250 ± 50 mbar	frequency converter	EF2
Purge gas supply pressure (optional)	PSL 220	-	2.4 bar(g)	customer PLC	EF7
Temperature pump Motor side (temperature limiter)	TSH 285	-	75 °C	frequency converter	EF3

Operation

Parameter	Designation	Warning threshold	Shut-off threshold	Processing by	Fault display
Temperature pump Gear side (Pt 1000)	TSH 280	50 °C (LVO 210) 45 °C (LVO 410)	60 °C (LVO 210) 50 °C (LVO 410)	frequency converter	PTF
Frequency converter temperature	TSH 281	105 °C	110 °C	frequency converter	oH oHi

7.4.6 Gas ballast operation



WARNING: EXPLOSION HAZARD

Risk of explosion and damage to the equipment. Explosive mixture can form within the gas chamber during the decompression process. Select the type of gas and purge gas quantity such that even under the most unfavourable circumstances no explosive mixture can occur.

The gas ballast is used to avoid condensation within the pump. To be effective, this requires the pump to attain its operating temperature.

7.4.7 Pumping of 100% Argon

- Constant working pressure between 1 and 80 mbar is possible.
- Working pressure > 80 mbar is permissible for maximum 5 minutes (30 minutes recovery afterwards) or at a reduced speed of 70 Hz without time limit.
- Working pressure < 1 mbar and for more than 5 minutes is only possible with N₂ purge.
- Argon is not permitted as purge gas.

Provide 20 slm N₂ or dry air as purge gas at the exhaust.

7.5 Shut-off and vent



WARNING: PUMP SAFETY

Risk of injury or damage to the equipment. Low purge gas flow during shut-off may damage the pump. Vent the pump only up to atmospheric pressure. If hazardous gases have been pumped previously, then follow safety information given in [Hazards caused by materials and substances](#) on page 14 and in the safety booklet.

When operation is finished, switch the pump off and proceed as follows:

- Isolate the pump from the chamber but keep it running.
- When pumping condensable media (water, for example) continue to operate the pump at a gas throughput, which is as high as possible for at least 30 minutes to dry it.
- Run the pump for 15 minutes with purge gas to make sure that it is free of process gases.
- Then switch off the pump.

DRYVAC without cooling water unit:

After switching off, maintain the cooling water flow for further 10 minutes, then shut off the cooling water feed.

Open the vacuum system only in the completely vented state and as short as possible. Otherwise humidity will collect on the inner surfaces. This will then, during subsequent evacuation, result in significantly longer pumpdown times until attaining the desired ultimate pressure.

If during longer downtimes the system shall remain conditioned for a rapid pumpdown, we recommend to vent in the system with dry nitrogen to atmospheric pressure and maintain it in this condition without opening it.

7.5.1 Process pump recovery after pump failure



WARNING: HAZARDOUS GASES

Risk of injury or damage to the equipment. If hazardous gases have been pumped previously then observe the safety information given in [Hazards caused by materials and substances](#) on page 14 and in the safety booklet.

If the pump stops during a process step there is a risk that the pump could contain hazardous materials, the following procedure should be followed in order to minimise the risk to people and property.

- When the process pump stops, interlock the process valve to close.
- Vent the system to atmospheric pressure using the respective purge gas.
- Purge the system for at least 15 minutes by opening all installed purge gas valves. With no purge gas connected to the pump, use a gas flow from the process side or a separate gas cylinder to purge the pump for at least 15 minutes.
- The lubricant must not be drained in any condition.
- Shut off the purge.
- Disconnect the pump exhaust and inlet and fit a metal ISO/NW blanking plate.
- Disconnect the purge gas supply and seal.
- The pump can now be removed to a workshop for decontamination and repair.

7.5.2 Remove from service

Shut off and vent the pump system as described in [Shut-off and vent](#) on page 68.

Clean the pump system of any substances which may lead to corrosion. (for example, by extended purge).

Flood it with nitrogen or dry purge gas, add desiccant and seal it.

Remove the cooling water from the pump system.

Remove the cooling water hoses from the pump and drain the cooling water. Blow out the cooling water coils with compressed air or nitrogen (maximum 4 bar). Blow into the cooling water inlet port only.

Also when storing the pump for longer periods of time the lubricant remains in the pump.

Maintenance

8 Maintenance

8.1 Maintenance intervals

Refer the [Table: Maintenance interval](#) for the recommended maintenance intervals for the pumps. We recommend a service contract with us.

We recommend to inspect the pump system and all components every 6 months under the process conditions. The inspection of the components shall detect the corrosion at an early stage and possible deposits of process dust. Depending on the findings, change in maintenance and replacement intervals can become necessary for specific components.

Table 12. Maintenance interval

Service work	Interval
Check the oil level	1 year
Oil change for synthetic oil	1 year
Oil change for PFPE	Not required
Clean the filter insert in the cooling water pressure reducer	Depending on the pollution degree of the cooling water
Check and clean the gas ballast filter	Depending on the specific ambient conditions
Replace the filter cartridge in the purge gas pressure reducer	1 year
Check the water hoses	1 year
Check the purge gas hoses	1 year
Complete overhaul in the service centre	Depending on the specific operating conditions
Check the leakage on the entire pump system	After all maintenance and assembly work and upon request

8.2 Change the oil

CAUTION: MAINTENANCE SAFETY



Risk of damage to the equipment. Refer [Electrical hazards](#) on page 12, [Thermal hazards](#) on page 13, [Hazards caused by materials and substances](#) on page 14 for safety information.

The oil-fill port must be sealed air-tight. In the presence of a vacuum, the entry of air may cause oil-containing gas to enter the pumping chamber via the impeller seals. When you do the maintenance of the pump, check the wiring and make sure that all the screws tight.

WARNING: HOT SURFACE



Risk of injury or damage to the equipment. Before you remove the oil-drain or oil-fill plug always switch off the pump first and vent to atmospheric pressure. If the pump has become warm during operation, the casing and the oil temperature may exceed 80 °C.

Leave the pump to cool down. Always wear protective gloves also to protect yourself against aggressive residues in the oil.

Maintenance

PFPE is not subjected to ageing, if used as intended. For this reason, it will not be exchanged. For safety reasons we recommend not to change the PFPE, since in the event of damage like mechanical failures, hazardous decomposition products may form. Only topping up PFPE will make sense and is possible should the lubricant level be too low after improper transportation, for example.

Change the synthetic oil more frequently if you pump corrosive vapours or large amount of dust.

Unscrew the oil-drain plugs, the oil-fill plugs and drain the oil.

Clean the sealing surface and firmly re-install the oil-drain plugs using a gasket which is in good condition. Wipe off oil residues from the casing.

Fill in new oil at a pump temperature of 15 °C to 25 °C. For this use a clean funnel.

Make sure to use the right kind of oil. Only use the oil supplied by the manufacturer. Refer [Accessories](#) on page 87.

Observe the correct oil fill levels for the shutdown (standing still) pump.

 **Note:**


If the oil level is too low, the bearings and gearwheels are not lubricated adequately. If it is too high, oil may enter the pumping chamber.

Clean the oil-fill port and re-install the plug using a gasket which is in perfect condition. Wipe off any oil residues from the casing.

Manually tighten the oil-fill plugs (tightening torque of approximately 10-15 Nm).

Maintenance

Figure 35. Oil change




- | | |
|-------------------|--------------------|
| A. Maximum - 0 mm | B. Minimum - 4 mm |
| 1. Oil fill plug | 2. Oil level glass |
| 3. Oil drain plug | 4. Oil drain plug |



Note:

The oil level shown is applicable when the pump is at standstill.
Purge gas or gas ballast valves and cooling water unit are not shown.

Figure 36. Maintenance on the air filter at the gas ballast valve



- | | |
|--|-----------------------------------|
| 1. Hexagon at the air filter (size 27) | 2. Dust cap of the air filter |
| 3. Compressed air gun | 4. Locking clip of the air filter |
| 5. Thread at the air filter | |

8.3 Cleaning the filter insert in the cooling water pressure reducer

Shut off the cooling water supply and discharge.

Unscrew the cartridge.

For this, a 27 mm hexagon pipe wrench is required. The adjustment knob can be pulled off should the inside of the wrench be too narrow.

Clean the filter insert with plain cold water.

8.4 Check and clean the gas ballast filter



CAUTION: COMPRESSED AIR

Risk of injury. When blowing out with compressed air, protect your eyes and wear protective goggles.

The air filter is used for filtering dust particles out of the air so that only clean air can enter the pump chamber.

The air filter should be subjected to maintenance within regular intervals.

Open the locking clips at the air filter and remove the dust cap from the air filter.

Use dry compressed air to blow out the filter.

Apply an open jaw spanner (size 27) to the hexagon and unscrew the filter element.

Blow out the filter element from the threaded side with compressed air. Re-seal the thread with Teflon tape and fit the filter element once more.

Fit the dust cap again and affix it with the locking clips.

8.5 Replace the filter cartridge in the purge gas pressure reducer



CAUTION: SAFETY INFORMATION

Observe the safety information given in [Important safety information](#) on page 10.

The filter cartridge in the purge gas module pressure reducer must be replaced annually, refer [Figure: Triple purge gas module](#).

To replace, unscrew the metal protection basket with cup from the pressure reducer. Unscrew the mounting component and detach the used filter cartridge. Fit the parts using a new filter cartridge again.

Fault finding

9 Fault finding

Table 13 Fault finding

Symptoms
<i>Pump does not start. EF2, EF3 or 100FT is displayed at the frequency converter</i> on page 74
<i>Pump gets too hot. At the frequency converter a Pt 1000 alarm is indicated</i> on page 74
<i>Pump is extremely loud</i> on page 75
<i>Motor power consumption is too high</i> on page 75
<i>Pump is too loud</i> on page 76
<i>Pump is losing lubricant (Lubricant leak is apparent)</i> on page 76
<i>Pump is losing lubricant (Lubricant leak is not apparent)</i> on page 76
<i>Oil gets too dark</i> on page 77
<i>Lubricant in the pump chamber</i> on page 77
<i>Pump does not attain its pumping speed</i> on page 77

Fault	Pump does not start. EF2, EF3 or 100FT is displayed at the frequency converter
-------	--

Cause	Motor is incorrectly connected.
Remedy	Connect motor correctly.
Cause	Over temperature switch or motor stator is defective.
Remedy	Contact us.
Cause	Pressure switch is defective.
Remedy	Replace the pressure switch.
Cause	Lubricant is too thick.
Remedy	Exchange the lubricant or warm up lubricant and the pump.
Cause	Motor rotor is defective.
Remedy	Contact us.
Cause	Pump has seized: defective impellers, bearings or toothed gears
Remedy	Contact us.

Fault	Pump gets too hot. At the frequency converter a Pt 1000 alarm is indicated
-------	--

Cause	Cooling water supply is not sufficient.
Remedy	Make sure sufficient cooling water is supplied.
Cause	Cooling water lines are clogged.
Remedy	Decalcify cooling water lines.
Cause	Filter insert in the pressure reducer is clogged.
Remedy	Clean the filter insert.

Fault finding

Cause	Ambient temperature is too high or cooling air flow is obstructed.
Remedy	Install the pump at a suitable place or make sure that there is sufficient flow of cooling air.
Cause	Pump is operating in the wrong pressure range.
Remedy	Check the pressure levels within the system.
Cause	Gas temperature is too high.
Remedy	Check the system.
Cause	Clearance between housing and rotors are too small due to contamination or distortion of the pump.
Remedy	Clean pumping chamber. Affix and connect the pump free of tension.
Cause	Friction resistance is too high due to contaminated bearings and/or contaminated lubricant.
Remedy	Clean pump, respectively perform maintenance.
Cause	Lubricant level is too high.
Remedy	Drain lubricant down to the correct level.
Cause	Lubricant level is too low.
Remedy	Top up lubricant to the correct level.
Cause	Wrong lubricant is filled in.
Remedy	Contact us.
Cause	Bearing is defective.
Remedy	Contact us.

Fault Pump is extremely loud

Cause	Bearing is damaged.
Remedy	Repair the pump.
Cause	Thick particle is deposited.
Remedy	Clean the pump, respectively perform maintenance.
Cause	Silencer is defective.
Remedy	Repair the silencer.
Cause	High gas throughput with the discharge line is open, without silencer.
Remedy	Install discharge line or silencer.

Fault Motor power consumption is too high

Cause	Pump gets too hot
Remedy	Refer remedy in Pump gets too hot. At the frequency converter a Pt 1000 alarm is indicated on page 74.

Fault finding

Cause	Incorrect mains voltage for the motor
Remedy	Connect the motor to the correct mains voltage.

Fault Pump is too loud

Cause Motor stator is defective.

Remedy Contact us.

Cause Motor rotor is defective.

Remedy Contact us.

Cause Distances between housing and rotors is too small due to contamination or distortion of the pump.

Remedy Clean pumping chamber. Affix and connect the pump free of tensions.

Cause Bearing or gear is damaged.

Remedy Shutdown pump immediately. Contact us.

Cause Pistons make contact with the housing.

Remedy Shutdown pump immediately. Contact us.

Cause Rotor is running untrue.

Remedy Shutdown pump immediately. Contact us.

Cause Oil slinger disc makes contact with the gear housing or the oil pipe.

Remedy Contact us.

Cause Oil pump is blocked or defective.

Remedy Shutdown pump immediately. Contact us.

Fault Pump is losing lubricant (Lubricant leak is apparent)

Cause Oil drain plug leaks

Remedy Drain lubricant, firmly screw in a new oil drain plug with the gasket, fill in correct lubricant quantity.

Cause Oil level glass leaks

Remedy Contact us.

Cause Gear cover leaks

Remedy Replace the O-ring of the gear cover.

Cause Puddle under the motor, leak in the seal

Remedy Shutdown pump immediately. Contact us.

Fault Pump is losing lubricant (Lubricant leak is not apparent)

Cause Lubricant in the pump chamber.

Remedy For remedy, refer [Lubricant in the pump chamber](#) on page 77.

Fault finding

Fault Oil gets too dark

Cause Oil has been used up.

Remedy LVO 210: Exchange the oil.
LVO 410: Contact us.

Cause Pump gets too hot.

Remedy Refer [Pump gets too hot. At the frequency converter a Pt 1000 alarm is indicated](#) on page 74. After the corrective action is taken for the malfunction, exchange the oil.

Fault Lubricant in the pump chamber

Cause Lubricant level is too high.

Remedy Drain the lubricant down to the correct level.

Cause Lubricant is ejected from the system.

Remedy Check the system.

Cause Pump is not standing horizontally.

Remedy Place the pump correctly.

Cause Pump has a gas leak towards outside.

Remedy Run a leak search and pinpoint leaks. If the leak is not at the oil-fill or oil-drain plugs, return the pump to the manufacturer. Contact us.

Cause Pump has an internal leak.

Remedy Contact us.

Cause Piston rings are defective.

Remedy Contact us.

Fault Pump does not attain its pumping speed

Cause Intake screen is clogged.

Remedy Clean intake screen.

Cause Motor is incorrectly connected.

Remedy Connect the motor correctly.

Cause Motor stator is defective.

Remedy Contact us.

Cause Motor rotor is defective.

Remedy Contact us.

Cause Vacuum pump system has a gas leak.

Remedy Detect leak and seal it.

Cause Impeller play is more than normal.

Remedy Contact us.

Fault finding

Cause **Bearing is defective.**

Remedy Contact us.

9.1 Fault and alarms displayed at the frequency converter

Faults and alarms indicate problems in the frequency converter or in the pump.





An alarm (warning) is indicated by a code on the data display and the flashing ALM LED. The frequency converter output is not necessarily switched off.

A fault is indicated by a code on the data display and the ALM LED is on. The frequency converter output is always switched off immediately and the motor coast to stop.







To remove an alarm or reset a fault, trace the cause, remove it and reset the frequency converter by pushing the reset key on the operator or cycling the power supply.

The lists up the most important alarms and faults only. Refer to Frequency converter manual (Publication number Y26/301007788 or YASKAWA GA500 maintenance and troubleshooting manual TOEPYAIGA5001A) for additional error codes which are missing in this manual. The error code information can be found on the frequency converter nameplate.








Table 14 Fault and alarms displayed at the frequency converter

Error message	Brief description	AL	FLT	Possible cause	Corrective action
	Control Fault			The torque limit was reached during deceleration for longer than 3 second when in Open Loop Vector control <ul style="list-style-type: none"> • The load inertia is too big. • The torque limit is too low. • The motor parameters are wrong. 	Check the load. Set the torque limit to the most appropriate setting (L7-01 through L7-04). Check the motor parameters.
	Control Circuit Fault		■	There is a problem in the control circuit of the frequency converter.	Cycle the frequency converter power supply. Initialise the frequency converter. Replace the frequency converter if the fault occurs again.
	Control Circuit Fault		■	There is no terminal board connected to the control board.	Check if the terminal board is installed properly. Uninstall and re-apply the terminal board. Change the frequency converter.
	Cannot Reset	■		Fault reset was input when a Run command was active.	Turn off the Run command and reset the frequency converter.

Fault finding

Error message	Brief description	AL	FLT	Possible cause	Corrective action
	Option External Fault	■	■	An external fault was tripped by the upper controller via an option card.	Remove the fault cause, reset the fault and restart the frequency converter. Check the upper controller programme.
	External Fault	■		A forward and reverse command were input simultaneously for longer than 500 ms. This alarm stops a running motor.	Check the sequence and make sure that the forward and reverse input are not set at the same time.
	External Faults	■	■	An external fault was triggered by an external device via one of the digital inputs S1 to S7. EF2: Pressure sensor exceeds fault threshold. EF3: Temperature limiter exceeds fault threshold. The digital inputs are set up incorrectly. EF7: If purge sensor is connected, the pressure is not enough. If purge sensor is not connected then bridge between wago clamp and S7 is missing.	Find out why the device tripped the EF. Remove the cause and reset the fault. Check the functions assigned to the digital inputs. EF2: Check exhaust line. EF3: Check motor load, reduce if required, improve cooling.
	Ground Fault		■	Ground leakage current has exceeded 50% of the frequency converters rated output current. Cable or motor insulation is broken. Excessive stray capacitance at frequency converter output.	Check the output wiring and the motor for short circuits or broken insulation. Replace the broken parts. Reduce the carrier frequency.
	Output Phase Loss		■	Output cable is disconnected or the motor winding is damaged. Loose wires at the frequency converter output. Motor is too small (less than 5% of frequency converter current).	Check the motor wiring. Make sure all terminal screws in the frequency converter and motor are properly tightened. Check the motor and frequency converter capacity.
	Overcurrent		■	Short circuit or ground fault on the frequency converter output side The load is too heavy. The acceleration/deceleration times are too short. Wrong motor data or V/f pattern settings. A magnetic contactor was switched at the output.	Check the output wiring and the motor for short circuits or broken insulation. Replace the broken parts. Check the machine for damages (gears, etc.) and repair any broken parts. Check the frequency converter parameter settings. Check the output contactor sequence.

Fault finding

Error message	Brief description	AL	FLT	Possible cause	Corrective action
	Heatsink Overheat	■	■	Surrounding temperature is too high. The cooling fan has stopped. The heatsink is dirty. The airflow to the heatsink is restricted.	Check the surrounding temperature and install cooling devices if necessary. Check the frequency converter cooling fan. Clean the heatsink. Check the airflow around the heatsink.
	Drive Overload		■	The load is too heavy. Too much torque at low speed.	Check the load. The overload capability is reduced at low speeds. Reduce the load or increase the frequency converter size.
	DC Overvoltage	■	■	DC bus voltage is too high. The deceleration time is too short. Stall prevention is disabled ¹ . Unstable motor control. Too high input voltage.	Increase the deceleration time. Enable stall prevention by parameter L3-04. Check motor parameter settings and adjust torque and slip compensation, AFR and hunting prevention as needed. Make sure that the power supply voltage meets the frequency converters specifications.
	Input Phase Loss		■	Input voltage drop or phase imbalance. One of the input phase is lost. Loose wires at the frequency converter input.	Check the power supply. Make sure that all cables are properly fixed to the correct terminals.
	DC Undervoltage	■	■	The voltage in the DC bus fell for longer than 2 second below the undervoltage detection level (L2-05). The power supply failed or one input phase has been lost. The power supply is too weak.	Check the power supply. Make sure, that the power supply is strong enough.
	Controller Undervoltage		■	The power supply voltage of the controller (of frequency converter) is too low.	Cycle power to the frequency converter. Check if the fault reoccurs. Replace the frequency converter if the fault continues to occur.
	DC Charge Circuit Fault		■	The charge circuit for the DC bus is broken.	Cycle power to the frequency converter. Check if the fault reoccurs. Replace the frequency converter if the fault reoccurs.

Fault finding

Error message	Brief description	AL	FLT	Possible cause	Corrective action
PTA1 / A2	Pt 1000 Alarm A1/2	■		Is true, when Pt 1000 measures temperatures of >50 °C (LVO 210) or >45 °C (LVO 410).	Check and improve cooling.
PTCA1 / A2	PTC and Pt 1000 Alarm A1/2	■		Is true, when PTC and Pt 1000 measures temperatures of >50 °C (LVO 210) or >45 °C (LVO 410).	Check and improve cooling.
PrECE	Pre CE alarm	■		Alarm is active for the time P5-01 before H5-09 elapsed during Memobus Communication error.	
EAL02	External Alarm during delay of MFDI set in S2	■		External alarm during delay of MFDI settings for S2 (H1-02). Pressure sensor exceeds alarm/ (warning)	
EAL03	External Alarm during delay of MFDI set in S3	■		External alarm during delay of MFDI settings for S3 (H1-03).	
L_SPd	Low Speed Detected		■	The output frequency is below the frequency set in P3-01 for the time set in P3-02.	
C-LiM	C-Lim Alarm	■		Drive was running at or above the Final Current Limit for the time P5-04 – P5-03	
PTFT			■	Open circuit is detected. Note "Wait" fault.	Check Pt 1000 and connection cable, replace if required.
				Short circuit is detected.	Check Pt 1000 and connection cable, replace if required.
				Is true, when Pt 1000 measures temperatures of >60 °C (LVO 210) or >50 °C (LVO 410). Note "Wait" fault.	Check and improve cooling.
CMPFT	Compensation Fault		■	Contact us.	

Fault finding

Error message	Brief description	AL	FLT	Possible cause	Corrective action
C-LiM	C-Lim Fault		■	Drive was running at or above the Final Current Limit for the time set by parameter P5-04.	
_AiT	Wait		■	<p>Condition for Pt 1000 Fault is reached. If the "Pt 1000 Open" threshold is reached within 10 seconds, then "Wait" changes to "Pt 1000 open", else it changes to "Pt 1000 fault".</p> <p>The fault is different to standard faults. There is no error code available and also no entry in the fault history. This ensures that only the faults "Pt 1000 open" and "Pt 1000 fault" can be seen or traced.</p> <p>As soon "Wait" is occurring the frequency converter stops with RUN to coast.</p>	

9.2 Operator programming errors

An Operator Programming Error (OPE) occurs when an inapplicable parameter is set or an individual parameter setting is inappropriate. When an OPE error is displayed, press the ENTER button to display U1-18 (OPE fault constant). This monitor will display the parameter that is causing the OPE error.

Table 15 Operator programming errors

Error message	Possible cause	Corrective action
oPE01	Drive capacity and value set to 02-04 do not match.	Contact service.
oPE02	Parameters were set outside the allowable setting range.	Set the parameters to the proper values.
oPE03	<p>A contradictory setting is assigned to multi-function contact inputs H1-01 through to H1-06.</p> <p>The same function is assigned to two inputs. (this excludes "External fault" and "Not used")</p> <p>Input functions which require the setting of other input functions were set alone.</p> <p>Input functions that are not allowed to be used simultaneously have been set.</p>	Fix any incorrect settings.
oPE05	<p>The run command source (b1-02) or frequency reference source (b1-01) is set to 3 but no option board is installed.</p> <p>The frequency reference source is set to pulse input but H6-01 is not 0.</p>	<p>Install the required option board.</p> <p>Correct the values set to b1-01 and b1-02.</p>
oPE07	<p>Settings to multi-function analog inputs H3-02 and H3-10 and PID functions conflict.</p> <p>H3-02 and H3-10 are set to the same value. (this excludes settings "0" and "F")</p> <p>PID functions have been assigned to both analog inputs and the pulse input at the same time.</p>	Fix any incorrect settings.

Fault finding

Error message	Possible cause	Corrective action
oPE08	A function has been set that cannot be used in the control mode selected.(might appear after control mode change)	Fix any incorrect settings.
oPE10	The V/f pattern setting is incorrect.	Check the V/f pattern settings.
oPE12	<p>Occurs if b1-01 (Frequency Reference) = 3 or b1-02 (Sequence Reference) =3 and Parameters Lower Level is set and option card is connected.</p> <p>Occurs if following condition is not given: P2-02 < P2-04 < P2-06 < P2-08 < P2-10 < P2-12 < P2-14 < P2-16 < P2-18 < P2-20 < P2-22.</p> <p>Occurs if following condition is not given: P4-01 < P4-02 < P4-03 < P4-04</p> <p>Occurs if MFDI setting in H1-02 is not an external fault setting and P1-05 is unequal to 0. ((H1-02 < 20h) OR (H1-02 > 2Fh)) AND (P1-05 NOT 0)</p> <p>Occurs if MFDI setting in H1-03 is not an external fault setting and P1-06 is unequal to 0. ((H1-03 < 20h) OR (H1-03 > 2Fh)) AND (P1-06 NOT 0)</p>	

Storage

10 Storage

Store the pumps only horizontally standing on their feet.

The pumps are filled with nitrogen for protection against corrosion and are sealed off. Open the pumps only immediately before installing them.

 **Note:**

If there is the danger of frost, the cooling water must be drained, refer [Remove from service](#) on page 69.

You may use a water glycol mixture of up to 30%.

Temperature (only for storage without cooling water)	-10 °C to +60 °C
Storage site	Dry
Maximum atmospheric humidity	95%, non-condensing

The pump must be stored at the most for one year only. Longer storing without turning the rotors will damage the bearings. Connect the pump to operate it briefly and then decommission the pump (The intake flange can stay sealed during this brief operation, the exhaust flange must be opened).


Capacitor forming – What has to be observed when an inverter was longer than 2 years on stock?

Refer to [Figure: Capacitor forming](#).

To prevent the deterioration of the capacitors, we recommend that you apply power to the drive a minimum of one time each year for at least 30 minutes.

If you store the drive for longer than two years and do not apply power, we recommend that you use a variable power source and gradually increase the power from 0 V to the rated drive voltage over a period of 2 to 3 minutes. Apply power for at least 1 hour with no load to reform the main circuit electrolytic capacitor. When you operate the drive after you apply the power, wire the drive correctly and check for drive faults, overcurrents, motor vibration, motor speed differences and other defects during operation.

Figure 37. Capacitor forming



11 Disposal



WARNING: CONTAMINATION HAZARD

Risk of contamination. Contaminated parts can be detrimental to health and environment. Before beginning with any work, first find out whether any parts are contaminated. Adhere to the relevant regulations and take the necessary precautions when handling contaminated parts.

The equipment may have been contaminated by the process or by environmental influences. In this case the equipment must be decontaminated in accordance with the relevant regulations. We offer this service at fixed prices. Further details are available on request.

Separate clean components according to their materials, and dispose of these accordingly. We offer this service. Further details are available on request.

When you send us the equipment, observe the regulations given in Return the equipment or components for service [Return the equipment or components for service](#) on page 86.

11.1 Disposal of waste oil

Owners of waste oil are entirely self-responsible for proper disposal of the waste oil.

Waste oil from vacuum pumps must not be mixed with other substances or materials.

Waste oil from vacuum pumps (oils which are based on mineral oils) which are subject to normal wear and which are contaminated due to the influence of oxygen in the air, high temperatures or mechanical wear must be disposed of through the locally available waste oil disposal system.

Waste oil from vacuum pumps which is contaminated with other substances must be marked and stored in such a way that the type of contamination is apparent. This waste must be disposed of as special waste.

European, national and regional regulations concerning waste disposal need to be observed. Waste must only be transported and disposed of by an approved waste disposal vendor.

PFPE from vacuum pumps may be regenerated, if required, and provided the quantities are large enough. For this, contact us for assistance.

12 Service

12.1 Return the equipment or components for service

Before you send your equipment to us for service or for any other reason, you must complete a Declaration of Contamination Form. The form tells us if any substances found in the equipment are hazardous, which is important for the safety of our employees and all other people involved in the service of your equipment. The hazard information also lets us select the correct procedures to service your equipment.

If you are returning equipment note the following:

- If the equipment is configured to suit the application, make a record of the configuration before returning it. All replacement equipment will be supplied with default factory settings.
- Do not return equipment with accessories fitted. Remove all accessories and retain them for future use.
- The instruction in the returns procedure to drain all fluids does not apply to the lubricant in pump oil reservoirs.

Download the latest documents from leybold.com/en/downloads/download-documents/declaration-of-contamination/, follow the procedure in HS1, fill in the electronic HS2 form, print it, sign it, and return the signed copy to us.



NOTICE:

If we do not receive a completed form, your equipment cannot be serviced.

13 Accessories

Table 16 Accessories

Accessory	Part number
	DV 650/800 DV 650/800 - r
Synthetic oil, ester oil, LEYBONOL LVO 210, 5 litres	L21005
PFPE LEYBONOL LVO 410, 1 litre	L41001
Profibus module for DRYVAC	112005A78
ProfiNet module for DRYVAC	112005A75
EtherCAT module for DRYVAC	112005A76
Relay module (digital output) for DRYVAC	112005A70
Ethernet module (dual port) for DRYVAC	112005A72
G3" Inlet adapter DRYVAC (female) G4" Inlet adapter DRYVAC (female)	112005A18 112005A19
Outlet flange DRYVAC DN 63 ISO K x 80 mm	112005A62
Adapter DRYVAC for RUVAC WH 700	112005A03
RUVAC WS(U) 1001	112005A04
RUVAC WS(U) 2001	112005A05
RUVAC WH(U) 2500	112005A07
RUVAC WH(U) 4400/7000	112005A10
Cooling water unit DRYVAC 450/650/800 S	112005A12
DRYVAC 450/650/800 S-r	112005A13
Fluid air cooling system FLKS-4S (heat exchanger) Kit glycol tubes for cooling system 112005A45	112005A45 112005A47
Non-return valve DRYVAC, DN 63 ISO-K	112005A15
Non-return valve for DRYVAC	112005A14
Gas ballast kit DRYVAC, 24 V electro-pneumatic	112005A17
Silencer DN 63 ISO-K for DRYVAC	119002
Serviceable silencer DN 63 ISO-K for DRYVAC	119003V
Stainless steel silencer DRYVAC 650/800	112005A50
External display	112005A80
Set of nozzles for DRYVAC purge gas (not for new purge gas modules)	112005A30
Permanent inlet purge kit (not for new purge gas modules)	112005A32
Castors for DV450/650 KIT (Set 4x)	504408V901
Frequency Converter IP66 for DV 650-r	112005A65
DRYVAC Energy Saver (only for DV/DV-r with LVO 210)	112005A60
Upgrade DRYVAC with Energy Saver, contains the DRYVAC Energy Saver and installation by Service	AS1406F

Accessories

Accessory	Part number
	DV 650/800 DV 650/800 - r
200 V filter	E6504287
200 V filter for IT grid	112005A26

For GSD file, manual for the Profibus interface and Ethernet IP driver see www.leybold.com/en/media/downloads/download-software/.

13.1 Ordering information

For all industrial applications as well as processes where quick pumping or short cycle times (for example, load lock chambers) are required, the DRYVAC industrial is the best solution.

The DRYVAC DV industrial versions (with the synthetic oil LVO 210) ensure a high suction capacity even above a pressure of 100 mbar. They were developed for short cycle operation and evacuating large vacuum chambers. These DRYVAC versions are also equipped with all the features for industrial applications.

Applications with a high oxygen content, corrosive gases, or PECVD processes require pumps with the LVO 410 (PFPE) lubricant. In these cases, the DRYVAC S or C (harsh applications) is the correct version.

Accessories

Table 17 Ordering data

DRYVAC	Frequency converter	Purge gas module	Gas ballast module (ambient air)	Cooling water unit	Cover and feet	Lubricant LEYBONOL	Part number
DRYVAC Industrial (synthetic oil)							
DV 650-r, 400 V	extern (Rack)	double	24 V valve	none	Rubber feet	LVO 210	112065V05-1
DV 650-r, 400 V	extern (Rack)	triple	none	none	Rubber feet	LVO 210	112065V07-1
DV 650 FP-r, 400 V IP 55	extern (Rack) (IP 66)	double	none	none	Rubber feet, epoxy-lacquer, washable	LVO 210	112065FP08-1
DV 650-r, 200 V	extern (Rack)	double	24 V valve	none	Rubber feet	LVO 210	112065V19-1
DV 650-r, 200 V	extern (Rack)	triple	none	none	Rubber feet	LVO 210	112065V19-2
DV 650, 400 V ATEX Cat 2i	on board	double	24 V valve	none	Rubber feet	LVO 210	112065V11-1
DV 650, 400 V	on board	triple	none	installed	Housing, castors, adjustable feet	LVO 210	112065V14-1
DV 650, 400 V with energy saver	on board	triple	none	installed	Housing, castors, adjustable feet	LVO 210	112065V14-2
DV 650 C, 400 V	on board	triple	none	installed	Housing, castors, adjustable feet	LVO 210	112065V14-3
DV 650, 400 V	on board	double	24 V valve	none	Rubber feet	LVO 210	112065V15-1
DV 650, 400 V with energy saver	on board	double	24 V valve	none	Rubber feet	LVO 210	112065V16-1
DV 650, 400 V	on board	triple	none	none	Rubber feet	LVO 210	112065V17-1
DV 650, 400 V with energy saver	on board	triple	none	none	Rubber feet	LVO 210	112065V18-1
DV 650 FP, 400 V	on board	triple	none	none	Rubber feet, epoxy-lacquer, washable	LVO 210	112065FP18-1
DV 650 S, 400 V	on board	single	none	installed	Rubber feet	LVO 210	112065V09-1
DV 650 plug and pump	on board	triple	none	installed	Housing, castors, adjustable feet	LVO 210	112065V75-1
DV 800-r, 400 V*	extern (Rack)	double	24 V valve	none	Rubber feet	LVO 210	112080V05-1

Accessories

DRYVAC	Frequency converter	Purge gas module	Gas ballast module (ambient air)	Cooling water unit	Cover and feet	Lubricant LEYBONOL	Part number
DV 800-r, 400 V*	extern (Rack)	triple	none	none	Rubber feet	LVO 210	112080V07-1
DV 800, 400 V*	on board	triple	none	installed	Housing, castors, adjustable feet	LVO 210	112080V14-1
DV 800, 400 V*	on board	double	24 V valve	none	Rubber feet	LVO 210	112080V15-1
DV 800, 400 V*	on board	triple	none	none	Rubber feet	LVO 210	112080V17-1
DV 800 plug and pump	on board	triple	none	installed	Housing, castors, adjustable feet	LVO 210	112080V75-1
DRYVAC PFPE							
DV 650 S, 400 V	on board	single	none	installed	Rubber feet	LVO 410	112065V20-1
DV 650 FP 400 V	on board	triple	none	none	Rubber feet, epoxy-lacquer, washable	LVO 410	112065FP28-1
DV 650 FP-r 200V	extern (Rack)	triple	none	none	Rubber feet, epoxy-lacquer, washable	LVO 410	112065FP29-1
DV 650 C, 400 V	on board	triple	none	installed	Rubber feet	LVO 410	112065V30-1
DV 650 C, 400 V LIB	on board	triple	none	installed	Rubber feet, also outside free of non-ferrous metal	LVO 410	112065V32-1
DV 650 C-r, 200 V	extern (Rack)	triple	none	installed	Rubber feet	LVO 410	112065V35-1
DV 650 C-r, 400 V with relay option board	extern (Rack)	triple	none	installed	Rubber feet	LVO 410	112065V36-1
DV 650 C-r, 200 V LIB	extern (Rack)	triple	none	none	Rubber feet, also outside free of non-ferrous metal	LVO 410	112065V37-1

* 2 mm purge at GS for venting

Accessories

13.2 Wearing parts

Table 18. Wearing parts

Accessory	Part number
Plug screw M16x1.5 (oil fill plug)	ES20127105
Gasket for plug screw	ES23955165
Filter cartridge for purge gas pressure reducer	E110000850
Air filter for gas ballast valve	E110000980
Pressure reducing cartridge for cooling water unit	E6519936

EU Declaration of Conformity



This declaration of conformity is issued under the sole responsibility of the manufacturer:

Leybold GmbH
Bonner Strasse 498
D-50968 Köln
Germany

Documentation Officer
T: +49(0) 221 347 0
documentation@leybold.com

The product specified and listed below

- Product: Screw vacuum pump - with Motor
- Models: DV650, DV800
- Pump family codes: 112065VXX-Z, 112065FPXX-Z, 112080VXX-Z, 112080FPXX-Z
XX = 01-99, Z = 1-9

Is in conformity with the relevant requirements of European CE legislation:

2006/42/EC	Machinery directive <i>Note: The safety objectives of the Low Voltage Directive 2014/35/EU were complied with in accordance with Annex 1 No. 1.5.1 of this directive.</i>
2014/30/EU	Electromagnetic compatibility (EMC) directive Class A Emissions, Industrial Immunity
2011/65/EU	Restriction of certain hazardous substances (RoHS) directive as amended by Delegated Directive (EU) 2015/863


Based on the relevant requirements of harmonised standards:

EN 1012-2:1996 +A1:2009	Compressors and vacuum pumps. Safety requirements. Vacuum pumps
EN 60204-1:2018	Safety of machinery. Electrical equipment of machines. General requirements
EN 61000-6-2:2019	Electromagnetic Compatibility (EMC) - Part 6-2: Generic Industrial Immunity Standard
EN 61000-6-4:2007 A1:2011	Electromagnetic Compatibility (EMC) - Part 6-4: Generic Industrial Emission Standard
EN IEC 63000:2018	Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

This declaration, based on the requirements of the listed Directives and EN ISO/IEC 17050-1, covers all product serial numbers from this date on: 2022-05-10

You must retain the signed legal declaration for future reference

This declaration becomes invalid if modifications are made to the product without prior agreement.



Andries De Bock
VP Engineering
Industrial Vacuum Division



Axel Guddas
General Manager
Product Company Cologne

Declaration of Conformity

Leybold GmbH
Bonner Strasse 498
D-50968 Köln
Germany

Documentation Officer
Innovation Drive
Burgess Hill
West Sussex
RH15 9TW
documentation@leybold.com

This declaration of conformity is issued under the sole responsibility of the manufacturer.

- Product: Screw vacuum pump - with Motor
- Models: DV650, DV800
- Pump family codes: 112065VXX-Z, 112065FPXX-Z, 112080VXX-Z, 112080FPXX-Z
XX = 01-99, Z = 1-9

The object of the declaration described above is in conformity with relevant statutory requirements:

Supply of Machinery (Safety) Regulations 2008

The objectives of the Electrical Equipment (Safety) Regulations 2016 are governed by Annex 1 1.5.1 of this regulation.

Electromagnetic Compatibility Regulations 2016

Class A Emissions, Industrial Immunity

Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

Relevant designated standards or technical specifications are as follows:

EN 1012-2:1996 +A1:2009	Compressors and vacuum pumps. Safety requirements. Vacuum pumps
EN 60204-1:2018	Safety of machinery. Electrical equipment of machines. General requirements
EN 61000-6-2:2019	Electromagnetic Compatibility (EMC) - Part 6-2: Generic Industrial Immunity Standard
EN 61000-6-4:2007 A1:2011	Electromagnetic Compatibility (EMC) - Part 6-4: Generic Industrial Emission Standard
EN IEC 63000:2018	Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

This declaration, based on the requirements of the listed Statutory Instruments and EN ISO/IEC 17050-1, covers all product serial numbers from this date on: 2022-05-10

You must retain the signed legal declaration for future reference

This declaration becomes invalid if modifications are made to the product without prior agreement.

Signed for and on behalf of Leybold GmbH



Andries De Bock
VP Engineering
Industrial Vacuum Division



Axel Guddas
General Manager
Product Company Cologne

ADDITIONAL LEGISLATION AND COMPLIANCE INFORMATION

EMC (EU, UK): Industrial equipment

Caution: This equipment is not intended for use in residential environments and may not provide adequate protection to radio reception in such environments.

RoHS (EU, UK): Material Exemption Information

This product is compliant with the following Exemptions

Annex III:

- 6(a) **Lead** as an alloying element in steel for machining purposes and in galvanised steel containing up to 0.35 % lead by weight
- 6(b) **Lead** as an alloying element in aluminium containing up to 0.4% by weight
- 6(c) Copper alloy containing up to 4% **lead** by weight

REACH (EU, UK)

This product is a complex article which is not designed for intentional substance release. To the best of our knowledge the materials used comply with the requirements of REACH. The product manual provides information and instruction to ensure the safe storage, use, maintenance and disposal of the product including any substance based requirements.

Article 33.1 Declaration (EU, UK)

This product contains Candidate List Substances of Very High Concern above 0.1%ww by article as clarified under the 2015 European Court of Justice ruling in case C-106/14.

- **Lead (Pb)**
This substance is present in certain steel / aluminium components.

TSCA PBTs (US)

Regulation of Persistent, Bioaccumulative, and Toxic Chemicals Under TSCA Section 6(h)

The product does not knowingly or intentionally contain substances in contravention with the above requirements.


Additional Applicable Requirements

The product is in scope for and complies with the requirements of the following:

2012/19/EU	Directive on waste electrical and electronic equipment (WEEE)
Product is certified to CSA-C22.2 No.61010-1-12	Safety requirements for electrical equipment for measurement, control and laboratory use – Part 1: General requirements
Product is certified to UL61010-1 3 rd Edition	Safety requirements for electrical equipment for measurement, control and laboratory use – Part 1: General requirements
cTUVus Certificate No.	CU 72190339

The product is certified by TÜV Rheinland of North America which is a “Nationally Recognized Testing Laboratory” (NRTL) for USA and Canada.

材料成分声明
China Material Content Declaration

部件名称 Part name 	有害物质 Hazardous Substances					
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr VI)	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
铸铝及铝合金制品 Aluminium alloys	X	O	O	O	O	O
钢合金制品 Steel alloys	X	O	O	O	O	O
铜接头 Brass connectors	X	O	O	O	O	O
<p>O: 表示该有害物质在该部件的所有均质材料中的含量低于 GB/T 26572 标准规定的限量要求。 O: Indicates that the hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.</p> <p>X: 表示该有害物质在该部件的至少一种均质材料中的含量超出 GB/T26572 标准规定的限量要求。 X: Indicates that the hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T26572.</p>						



Pioneering products. Passionately applied.

Leybold GmbH
Bonner Strasse 498
50968 Cologne
GERMANY
+49-(0)221-347-0
info@leybold.com
www.leybold.com